

MaxiSys_Citroen_V4.32 Function List (Note:For reference only)

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
BERLINGO	Injection	Petrol engine	1.1 L HDY/HDZ BOSCH	●			●		
BERLINGO	Injection	Petrol engine	1.4 L KFX MM1AP	●			●		
BERLINGO	Injection	Petrol engine	1.8 L LFX MM1AP	●			●		
BERLINGO	Injection	Petrol engine	1.1 L HDY/HDZ BOSCH	●			●		
BERLINGO	Injection	Petrol engine	1.1 L HFX BOSCH M7.4.4	●	●	●	●	●	
BERLINGO	Injection	Petrol engine	1.4 L KFW SAGEM S2000	●			●	●	
BERLINGO	Injection	Petrol engine	1.4 L KFW SAGEM S2000	●			●	●	
BERLINGO	Injection	Petrol engine	1.4L KFX SAGEM SL96	●			●	●	
BERLINGO	Injection	Petrol engine	1.4 L KFX BOSCH MP7.3	●			●	●	
BERLINGO	Injection	Petrol engine	1.8 L LFX MM1AP	●			●		
BERLINGO	Injection	Diesel engine	2.0 L RHY BOSCH EDC15C2	●	●	●	●	●	
BERLINGO	Injection	Diesel engine	1.9 L WJY LUCAS DCN2	●	●	●	●	●	
BERLINGO	Anti-lock brake system	ABS electronic distribution		●			●	●	
BERLINGO	Injection	Diesel engine	RHY SIEMENS SID801	●	●	●	●	●	
BERLINGO	Airbag			●					
BERLINGO	BSI			●			●	●	
BERLINGO	Radio post-equipment			●			●	●	
BERLINGO	CD player			●			●	●	
BERLINGO	Instrument panel			●			●	●	
BERLINGO	Airbag	Airbag TRW		●					
BERLINGO	Airbag	Airbag AUTOLIV		●					
BERLINGO (B9)	ABS	ESP8.1 BOSCH		●	●	●	●	●	05007 06001
BERLINGO (B9)	ABS	ABS8.1 BOSCH		●	●	●	●	●	06001
BERLINGO (B9)	Injection	Petrol engine	MEV174	●	●	●	●	●	07002
BERLINGO (B9)	Injection	Petrol engine	NFU BOSCH ME745	●	●	●	●	●	
BERLINGO (B9)	Injection	Petrol engine	N6A BOSCH ME745	●	●	●	●	●	
BERLINGO (B9)	Injection	Petrol engine	NFS BOSCH ME745	●	●	●	●	●	
BERLINGO (B9)	Injection	Petrol engine	NFR BOSCH ME745	●	●	●	●	●	
BERLINGO (B9)	Injection	Petrol engine	MEV17 4 2	●	●	●	●	●	
BERLINGO (B9)	Injection	Diesel engine	9HT BOSCH EDC16C34 DV6BUTED4-75CV	●	●	●	●	●	
BERLINGO (B9)	Injection	Diesel engine	9HT BOSCH EDC16C34 DV6BTED4-75CV	●	●	●	●	●	
BERLINGO (B9)	Injection	Diesel engine	9HZ (FAP) BOSCH EDC16C34 DV6TED4-110CV	●	●	●	●	●	
BERLINGO (B9)	Injection	Diesel engine	9HX BOSCH EDC16C34 DV6AUTED4- 90CV	●	●	●	●	●	

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
BERLINGO (B9)	Injection	Diesel engine	9HX BOSCH EDC16C34 DV6ATED4- 90CV	●	●	●	●	●	
BERLINGO (B9)	Injection	Diesel engine	9HV FAP BOSCH EDC16C34 DV6TED4B-90CV	●	●	●	●	●	
BERLINGO (B9)	Injection	Diesel engine	9HS FAP BOSCH EDC16C34 DV6TED4BU-90CV	●	●	●	●	●	
BERLINGO (B9)	Injection	Diesel engine	HDI SID807 BR2	●	●	●	●	●	
BERLINGO (B9)	BSI			●	●	●	●	●	03005
BERLINGO (B9)	Instrument panel			●	●	●	●		
BERLINGO (B9)	Radio	Radio post-equipment		●	●	●	●	●	
BERLINGO (B9)	CD player			●	●	●		●	
BERLINGO (B9)	Parking aid			●	●	●	●		
BERLINGO (B9)	Air conditioning			●	●	●	●	●	
BERLINGO (B9)	Switch module under the steering wheel			●	●	●	●	●	
BERLINGO (B9)	Alarm			●	●	●	●	●	
BERLINGO (B9)	Trailer relay unit			●	●	●	●	●	
BERLINGO (B9)	Engine relay unit			●	●	●	●	●	
BERLINGO (B9)	Rain sensor/ Brightness			●	●	●			
BERLINGO (B9)	Airbag			●	●	●	●		
BERLINGO (B9)	Multifunction screen(EMF)	Type "A" (segments)		●	●	●	●		
BERLINGO (B9)	Multifunction screen(EMF)	Type "C" (dot matrix)		●	●	●	●		
BERLINGO (B9)	Telematic	RNEG navigation radio		●	●	●	●		
BERLINGO (B9)	Multiplexed diesel additive pump			●	●	●	●	●	
BERLINGO (B9)	Power steering	Electric pump unit(GEP)		●	●	●	●	●	
BERLINGO (B9)	Hands Free Kit	Mobile Housing		●	●	●	●	●	
BERLINGO (B9)	Bodywork Conversion Unit			●	●	●	●	●	
BERLINGO (B9)	Deflation detection			●	●	●	●		02003 02007 02008 02009 02010 02012
BERLINGO (B9)	Deflation detection		DSG UDS	●	●	●	●		
BERLINGO (B9)	Anti-slip mode selector			●			●	●	
BERLINGO 2	Anti-lock brake system	ABS8.1 BOSCH		●	●	●	●	●	06001
BERLINGO 2	Anti-lock brake system	ABS8 BOSCH			●	●		●	06001
BERLINGO 2	Anti-lock brake system	ABR5.3		●			●	●	
BERLINGO 2	Injection	Petrol engine	TU3A J34P	●	●	●	●	●	
BERLINGO 2	Injection	Petrol engine	MM48P	●	●	●	●	●	07001
BERLINGO 2	Injection	Petrol engine	ME749	●	●	●	●	●	07003
BERLINGO 2	Injection	Petrol engine	2.0L RFN MM48P	●	●	●	●	●	07001
BERLINGO 2	Injection	Petrol engine	NFU BOSCH ME744	●	●	●	●	●	
BERLINGO 2	Injection	Petrol engine	KFV SAGEM S2000PM1		●	●		●	
BERLINGO 2	Injection	Petrol engine	KFV SAGEM S2000PM2		●	●			
BERLINGO 2	Injection	Petrol engine	NFS BOSCH ME745	●	●	●	●	●	
BERLINGO 2	Anti-lock brake system	ESP8.1 BOSCH		●	●	●	●	●	05007
BERLINGO 2	Anti-lock brake system	ESP BOSCH5.7		●	●	●	●	●	05003 06001
BERLINGO 2	Anti-lock brake system	ESP8 BOSCH			●	●		●	05003 06001
BERLINGO 2	Injection	Petrol engine	NFU BOSCH ME745	●	●	●	●	●	

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
BERLINGO 2	Injection	Petrol engine	N6A BOSCH ME745	●	●	●	●	●	
BERLINGO 2	Injection	Petrol engine	NFR BOSCH ME745	●	●	●	●	●	
BERLINGO 2	Injection	Diesel engine	9HX BOSCH EDC16C34 DV6ATED4	●	●	●	●	●	
BERLINGO 2	Injection	Diesel engine	RHY SIEMENS SID801	●	●	●	●	●	
BERLINGO 2	Injection	Diesel engine	RHY SIEMENS SID801		●	●		●	
BERLINGO 2	Injection	Diesel engine	WJY DCN2	●	●	●	●	●	
BERLINGO 2	BSI			●	●	●	●	●	03005
BERLINGO 2	Instrument panel			●	●	●	●	●	
BERLINGO 2	Radio post-equipment			●	●	●	●	●	
BERLINGO 2	CD player			●	●	●	●	●	
BERLINGO 2	Parking aid			●	●	●	●	●	
BERLINGO 2	Alarm			●	●	●		●	
BERLINGO 2	Switch module at the steering wheel	Top of column			●	●			
BERLINGO 2	Rain sensor/ Brightness			●	●	●	●		
BERLINGO 2	Airbag			●	●	●			
BERLINGO 2	Display or Telematics	Multifunction display SAGEM A		●	●	●	●	●	
BERLINGO 2	Display or Telematics	Multifunction display SAGEM B		●	●	●	●	●	
BERLINGO 2	Display or Telematics	Telematics unit		●	●	●	●	●	
BERLINGO 2	Gas injection	SAX500 GPL			●	●		●	
BERLINGO 2	Gas injection	SAX500 GNV			●	●		●	
BERLINGO 2	additional heating			●	●	●	●	●	
C1	ABS	ABS anti-lock braking system			●	●	●	●	
C1	ABS	ESP S2000 ABS			●	●	●	●	
C1	ABS	ABS90 T			●	●	●	●	
C1	Injection	Petrol engine	384 F injection		●	●	●	●	
C1	Injection	Diesel engine	DV4 injection	●	●	●	●	●	
C1	Gearbox ECU	Sequential manual gearbox (MMT)			●	●	●	●	
C1	Airbag			●	●	●	●		
C1	Immobiliser control module(Immobiliser)				●	●	●		
C1	Electric power steering			●	●	●	●		
C15	Engine	Diesel engine	1.9 L WJY LUCAS DCN2	●	●	●	●	●	
C2 CHINE	ABS			●	●	●	●	●	06001
C2 CHINE	Injection	Petrol engine	1.6 L NFU BOSCH ME745	●	●	●	●	●	
C2 CHINE	Injection	Petrol engine	J34P	●	●	●	●	●	
C2 CHINE	BSI			●	●	●	●	●	03005
C2 CHINE	Instrument panel			●	●	●	●	●	
C2 CHINE	Air conditioning			●	●	●	●	●	
C2 CHINE	Steering wheel with fixed central controls	Top of column			●	●			
C2 CHINE	Airbag			●	●	●			

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
C2 CHINE	Gearbox ECU	Auto gearbox AL4 TA2000		●			●	●	07001
C2 CHINE	Gearbox ECU	Auto gearbox AL4 TA2000		●			●	●	07001
C2 CHINE	Gearbox ECU	Auto gearbox AL4 TA2000		●			●	●	07001
C2 CAN	Injection	Petrol engine	KFU MM6LPC	●	●	●	●	●	07001
C2 CAN	Injection	Petrol engine	TU1A J34P	●	●	●	●	●	07003
C2 CAN	Injection	Petrol engine	TU3A J34P	●	●	●	●	●	07003
C2 CAN	Injection	Petrol engine	NFS BOSCH ME745	●	●	●	●	●	
C2 CAN	Injection	Petrol engine	NFU BOSCH ME745	●	●	●	●	●	
C2 CAN	Injection	Petrol engine	N6A BOSCH ME745	●	●	●	●	●	
C2 CAN	Anti-lock brake system	ABS MK70		●	●	●	●	●	06001
C2 CAN	Anti-lock brake system	ABS MK70.1		●	●	●	●	●	06001
C2 CAN	BSI			●	●	●	●	●	03005
C2 CAN	Instrument panel			●	●	●	●	●	
C2 CAN	Radio	Radio post-equipment		●	●	●	●	●	
C2 CAN	CD player			●	●	●	●	●	
C2 CAN	Parking aid			●	●	●	●	●	
C2 CAN	Air conditioning			●	●	●	●	●	
C2 CAN	Alarm			●	●	●	●	●	
C2_CAN	Switch module under the steering wheel	Top of column		●	●	●	●	●	
C2 CAN	Rain sensor/ Brightness			●	●	●			
C2 CAN	Airbag			●	●	●	●		
C2 CAN	Multifunction screen	Multifunction screen A		●	●	●	●		
C2 CAN	Multifunction screen	Multifunction screen C		●	●	●	●	●	
C2 CAN	Telematic	Telematics (RT3)		●	●	●	●	●	
C2 CAN	Telematic	Telematic (RT4)		●	●	●	●	●	
C2 CAN	Telematic	Telematic (RT5)		●	●	●	●		
C2 CAN	High frequency receiver			●	●	●	●		
C2 CAN	Injection	Petrol engine	NFR BOSCH ME745	●	●	●	●	●	
C2 CAN	Injection	Petrol engine	KFV SAGEM S2000PM2		●	●		●	
C2_CAN	Injection	Diesel engine	9HZ (FAP) BOSCH EDC16C34 DV6TED4	●	●	●	●	●	
C2 CAN	Injection	Diesel engine	8HZ BOSCH EDC16C34 DV4TD	●	●	●	●	●	
C2 CAN	Injection	Diesel engine	8HZ SIEMENS SID806	●	●	●	●	●	
C2 CAN	Trailer relay unit			●	●	●	●	●	
C2 CAN	Engine relay unit			●	●	●	●	●	
C2 CAN	Anti-lock brake system	ESP MK60		●	●	●	●	●	05001 06001
C2 CAN	Anti-lock brake system	ESP MK60-0		●	●	●	●	●	05002 06001
C2 CAN	Gearbox ECU			●	●	●	●	●	
C2 CAN	Electric power steering ECU			●	●	●	●		
C2 CAN	Hands Free Kit			●	●	●	●	●	
C2_CAN	ECU Reversible "Stop-Start" alternator			●	●	●	●	●	
C2 VAN	BSI			●	●	●	●	●	03005
C2 VAN	Instrument panel			●	●	●	●	●	
C2 VAN	Radio			●	●	●	●	●	
C2 VAN	CD player			●	●	●	●	●	

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
C2 VAN	Parking aid			●	●	●	●	●	
C2 VAN	Air conditioning			●	●	●	●	●	
C2 VAN	Navigation			●	●	●	●		
C2 VAN	Alarm			●	●	●	●	●	
C2 VAN	Switch module under the steering wheel	Top of column		●	●	●	●		
C2 VAN	Rain sensor/ Brightness			●	●	●	●		
C2 VAN	Airbag			●	●	●	●		
C2 VAN	Display or Telematics	Multifunction display SAGEM A		●	●	●	●	●	
C2 VAN	Display or Telematics	Multifunction display SIEMENS B		●	●	●	●	●	
C2 VAN	Display or Telematics	Multifunction display SIEMENS C		●	●	●	●	●	
C2 VAN	Display or Telematics	Telematics unit		●	●	●	●	●	
C2 VAN	Gearbox ECU	Controlled manual gearbox ECU		●	●	●	●	●	
C2 VAN	Electric power steering ECU			●	●	●	●		
C2 VAN	Injection	Petrol engine	HFX MM48P	●	●	●	●	●	07001
C2 VAN	Injection	Petrol engine	NFU BOSCH ME744	●	●	●	●	●	
C2 VAN	Injection	Petrol engine	NFS BOSCH ME744	●	●	●	●	●	
C2 VAN	Injection	Petrol engine	KFV SAGEM S2000PM1		●	●		●	
C2 VAN	Injection	Petrol engine	KFV SAGEM S2000PM1		●	●		●	
C2 VAN	Injection	Petrol engine	KFV SAGEM S2000PM2		●	●			
C2 VAN	Anti-lock brake system	ABS		●	●	●	●	●	06001
C2 VAN	Anti-lock brake system	ESP		●	●	●	●	●	05001 06001
C2 VAN	Injection	Diesel engine	8HZ BOSCH EDC16C34 DV4TD	●	●	●	●	●	
C2 VAN	Injection	Diesel engine	8HX BOSCH EDC16C34 DV4TD	●	●	●	●	●	
C2 VAN	Injection	Diesel engine	8HX SIEMENS SID802	●	●	●	●	●	
C2 VAN	Injection	Diesel engine	8HX SIEMENS SID804		●	●		●	
C2 VAN	Injection	Diesel engine	8HX SIEMENS SID804		●	●		●	
C2 VAN	Injection	Diesel engine	8HZ SIEMENS SID804		●	●		●	
C2 VAN	Injection	Diesel engine	8HZ SIEMENS SID804		●	●		●	
C3	BSI			●	●	●	●	●	03005
C3	Instrument panel			●	●	●	●	●	
C3	Radio	Radio post-equipment		●	●	●	●	●	
C3	CD player			●	●	●	●	●	
C3	Parking aid			●	●	●	●	●	
C3	Air conditioning			●	●	●	●	●	
C3	Navigation			●	●	●	●		
C3	Alarm				●	●		●	
C3	Switch module under the steering wheel	Top of column			●	●			
C3	Rain sensor/ Brightness				●	●			
C3	Driving school mode			●			●	●	
C3	Airbag			●	●	●	●		

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
C3	Multifunction display	Multifunction display SAGEM A		●	●	●	●	●	
C3	Multifunction display	Multifunction display SIEMENS B		●	●	●	●	●	
C3	Multifunction display	Multifunction display SIEMENS C		●	●	●	●	●	
C3	Multifunction display	Telematics unit		●	●	●	●	●	
C3	Telematic	RASTREADOR		●	●	●	●		
C3	Diesel additive function			●	●	●	●	●	04008
C3	Injection	Petrol engine	HFX MM48P	●	●	●	●	●	07001
C3	Injection	Petrol engine	KFU MM6LP	●	●	●	●	●	
C3	Injection	Petrol engine	KFU MM6LP	●	●	●	●	●	
C3	Injection	Petrol engine	NFU BOSCH ME744	●	●	●	●	●	
C3	Injection	Petrol engine	N6A BOSCH ME744	●	●	●	●	●	
C3	Injection	Petrol engine	KFV BOSCH ME744	●	●	●	●	●	
C3	Injection	Petrol engine	KFV SAGEM S2000PM1		●	●		●	
C3	Injection	Petrol engine	KFV SAGEM S2000PM1	●	●	●	●	●	
C3	Injection	Petrol engine	KFV SAGEM S2000PM2		●	●			
C3	Injection	Petrol engine	NFU BOSCH ME749	●	●	●	●	●	
C3	Injection	Petrol engine	N6A BOSCH ME749	●	●	●	●	●	
C3	Injection	Petrol engine	NFS BOSCH ME749	●	●	●	●	●	
C3	Injection	Petrol engine	NFR BOSCH ME749	●	●	●	●	●	
C3	Injection	Petrol engine	KFV BOSCH ME749	●	●	●	●	●	
C3	Injection	Diesel engine	9HZ (FAP) BOSCH EDC16C34 DV6TED4	●	●	●	●	●	
C3	Injection	Diesel engine	9HX BOSCH EDC16C34 DV6ATED4	●	●	●	●	●	
C3	Gas injection	SAX500 GPL			●	●		●	
C3	Gas injection	SAX500 GNV			●	●		●	
C3	Anti-lock brake system	ABS MK60		●			●	●	06001
C3	Anti-lock brake system	ABS MK70		●	●	●	●	●	06001
C3	Anti-lock brake system	ESP		●	●	●	●	●	05001 06001
C3	Gearbox ECU	Auto gearbox AL4		●			●	●	07001
C3	Gearbox ECU	Auto gearbox AL4		●			●	●	07001
C3	Gearbox ECU	Auto gearbox AL4		●			●	●	07001
C3	Gearbox ECU	Controlled manual gearbox ECU		●	●	●	●	●	
C3	Electric power steering ECU			●	●	●	●		
C3	ECU Reversible "Stop-Start" alternator			●	●	●	●	●	
C3	Injection	Diesel engine	8HX SIEMENS SID802	●	●	●	●	●	
C3	Injection	Diesel engine	8HX SIEMENS SID804		●	●		●	
C3	Injection	Diesel engine	8HX SIEMENS SID804		●	●		●	
C3	Injection	Diesel engine	8HZ SIEMENS SID804		●	●		●	
C3	Injection	Diesel engine	8HZ SIEMENS SID804		●	●		●	
C3	Injection	Diesel engine	8HY DELPHI C6	●	●	●	●	●	
C3	Injection	Diesel engine	8HY DELPHI C6	●	●	●	●	●	

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
C3 (A51)	Auto gearbox		BVA AL4	●	●	●	●	●	07001
C3 (A51)	Auto gearbox		MAPS UDS	●	●	●	●	●	
C3 (A51)	Auto gearbox		CFC300P	●	●	●	●	●	
C3 (A51)	Injection		J34P	●	●	●	●	●	07003
C3 (A51)	Injection		MED17.4	●	●	●	●	●	07002
C3 (A51)	Injection		MEV174	●	●	●	●	●	07002
C3 (A51)	Injection		V34.1	●	●	●	●	●	07001
C3 (A51)	Injection		MEV17 4 2	●	●	●	●	●	07002
C3 (A51)	Injection		EDC16C3	●	●	●	●	●	
C3 (A51)	Injection		HDI SID807 BR2	●	●	●	●	●	
C3 (A51)	Injection		V46	●	●	●	●	●	
C3 (A51)	ABS		ABSMK100	●	●	●	●	●	
C3 (A51)	ABS		ESPMK100	●	●	●	●	●	
C3 AIRCROSS	Auto gearbox		BVA AL4	●	●	●	●	●	07001
C3 AIRCROSS	Injection		ME749	●	●	●	●	●	07003
C3 PICASSO	BSI			●	●	●	●	●	03005
C3 PICASSO	Seat belt reminder LED			●				●	
C3 PICASSO	Instrument panel			●	●	●	●		
C3 PICASSO	Radio	Radio post-equipment		●	●	●	●	●	
C3 PICASSO	Parking aid			●	●	●	●		
C3 PICASSO	Air conditioning			●	●	●	●	●	
C3 PICASSO	Alarm			●	●	●	●	●	
C3 PICASSO	Switch module under the steering wheel			●	●	●	●	●	
C3 PICASSO	Rain sensor/ Brightness			●	●	●			
C3 PICASSO	Airbag			●	●	●	●		
C3 PICASSO	Multifunction screen(EMF)	Type "A" (segments)		●	●	●	●		
C3 PICASSO	Multifunction screen(EMF)	Type "C" (dot matrix)		●	●	●	●		
C3 PICASSO	Telematic			●	●	●	●		
C3 PICASSO	Multiplexed diesel additive pump			●	●	●	●	●	
C3 PICASSO	Engine relay unit			●	●	●	●	●	
C3 PICASSO	Trailer relay unit			●	●	●	●	●	
C3 PICASSO	Power steering	Electric power steering		●	●	●	●		
C3 PICASSO	Hands Free Kit			●	●	●	●	●	
C3 PICASSO	Driver's door control panel			●	●	●	●		
C3 PICASSO	ABS		ESP MK60		●	●		●	05001
C3 PICASSO	ABS		ABS MK 70.2	●	●	●	●	●	
C3 PICASSO	ABS		ABSMK100	●	●	●	●	●	
C3 PICASSO	ABS		ESPMK100	●	●	●	●	●	
C3 PICASSO	Injection	Petrol engine	5FW MEV17.4	●	●	●	●	●	07002
C3 PICASSO	Injection	Petrol engine	8FS MEV17.4	●	●	●	●	●	07002
C3 PICASSO	Injection	Diesel engine	9HZ (FAP) BOSCH EDC16C34 DV6TED4-110CV	●	●	●	●	●	
C3 PICASSO	Injection	Diesel engine	9HX BOSCH EDC16C34 DV6ATED4- 90CV	●	●	●	●	●	
C3 PICASSO	Injection	Diesel engine	HDI SID807 BR2	●	●	●	●	●	

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
C3 PICASSO	Gearbox		CFC300P	●	●	●	●	●	
C3 PICASSO Ai58	Injection/ignition		ME749	●	●	●	●	●	07004
C3 PICASSO Ai58	Injection/ignition		ME749 EC5	●	●	●	●	●	07004
C3 PICASSO Ai58	Injection/ignition		V34.4	●	●	●	●	●	07004
C3 PICASSO Ai58	Injection/ignition		V34.5	●	●	●	●	●	
C3 PICASSO Ai58	ABS/traction control		ABSMK70 1	●	●	●	●	●	
C3 PICASSO Ai58	ABS/traction control		ESPMK60 0	●	●	●	●	●	05002
C3 PICASSO Ai58	Gearbox		BVA AL4	●	●	●	●	●	07004
C3 PICASSO Ai58	Built-in Systems Interface (BSI)			●	●	●	●	○	
C3 PICASSO Ai58	Trailer relay unit			●	●	●	●	○	
C3 PICASSO Ai58	Telematics			●	●	●	●	●	
C3 PICASSO Ai58	Services module			●	●	●	●	●	
C3 PICASSO Ai58	Instrument panel			●	●	●	●	●	
C3 PICASSO Ai58	Radio			●	●	●	●	●	
C3 PICASSO Ai58	Anti-theft alarm			●	●	●	●	●	
C3 PICASSO Ai58	Driver and passenger airbags		SAC_AUTOLIV	●	●	●	●	○	
C3 PICASSO Ai58	Air conditioning			●	●	●	●	●	
C3 PICASSO Ai58	Parking aid			●	●	●	●	○	
C3 PICASSO Ai58	Rain and brightness sensor (CDPL)			●	●	●	●	○	
C3 PICASSO Ai58	Switch module under the steering wheel (top of column)			●	●	●	●	●	
C3 PICASSO (A58)	Injection		MED17.4	●	●	●	●	●	07002
C3 PICASSO (A58)	Injection		MEV174	●	●	●	●	●	07002
C3 PICASSO (A58)	Injection		MEV17 4 2	●	●	●	●	●	07002
C3 PLURIEL CAN	BSI			●	●	●	●	●	03005
C3 PLURIEL CAN	Instrument panel			●	●	●	●	●	
C3 PLURIEL CAN	Radio	Radio post-equipment		●	●	●	●	●	
C3 PLURIEL CAN	CD player			●	●	●	●	●	
C3 PLURIEL CAN	Parking aid			●	●	●	●	●	
C3 PLURIEL CAN	Air conditioning			●	●	●	●	●	
C3 PLURIEL CAN	Alarm			●	●	●	●	●	
C3 PLURIEL_CAN	Switch module under the steering wheel	Top of column		●	●	●	●	●	
C3 PLURIEL CAN	Rain sensor/ Brightness			●	●	●	●	●	
C3 PLURIEL CAN	Sun roof			●	●	●	●	●	
C3 PLURIEL CAN	Airbag			●	●	●	●	●	
C3 PLURIEL CAN	Multifunction screen	Multifunction screen A		●	●	●	●	●	
C3 PLURIEL CAN	Multifunction screen	Multifunction screen C		●	●	●	●	●	
C3 PLURIEL CAN	Telematic	Telematics (RT3)		●	●	●	●	●	
C3 PLURIEL CAN	Telematic	Telematic (RT4)		●	●	●	●	●	
C3 PLURIEL CAN	Telematic	Telematic (RT5)		●	●	●	●	●	
C3 PLURIEL CAN	High frequency receiver			●	●	●	●	●	
C3 PLURIEL CAN	Trailer relay unit			●	●	●	●	●	

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
C3 PLURIEL CAN	Engine relay unit			●	●	●	●	●	
C3 PLURIEL CAN	Gearbox ECU			●	●	●	●	●	
C3 PLURIEL CAN	Electric power steering ECU			●	●	●	●		
C3 PLURIEL CAN	Hands Free Kit			●	●	●	●	●	
C3 PLURIEL CAN	Injection	Petrol engine	TU1A J34P	●	●	●	●	●	07003
C3 PLURIEL CAN	Injection	Petrol engine	TU3A J34P	●	●	●	●	●	07003
C3 PLURIEL CAN	Injection	Petrol engine	NFS BOSCH ME745	●	●	●	●	●	
C3 PLURIEL CAN	Injection	Petrol engine	NFU BOSCH ME745	●	●	●	●	●	
C3 PLURIEL CAN	Injection	Petrol engine	N6A BOSCH ME745	●	●	●	●	●	
C3 PLURIEL CAN	Injection	Petrol engine	NFR BOSCH ME745	●	●	●	●	●	
C3 PLURIEL CAN	Injection	Diesel engine	8HZ BOSCH EDC16C34 DV4TD	●	●	●	●	●	
C3 PLURIEL CAN	Injection	Diesel engine	8HZ SIEMENS SID806	●	●	●	●	●	
C3 PLURIEL CAN	Anti-lock brake system	ABS MK70		●	●	●	●	●	
C3 PLURIEL CAN	Anti-lock brake system	ABS MK70.1		●	●	●	●	●	
C3 PLURIEL CAN	Anti-lock brake system	ESP MK60		●	●	●	●	●	05002
C3 PLURIEL CAN	Anti-lock brake system	ESP MK60-0		●	●	●	●	●	05001
C3 PLURIEL VAN	BSI			●	●	●	●	●	03005
C3 PLURIEL VAN	Instrument panel			●	●	●	●	●	
C3 PLURIEL VAN	Radio	Radio post-equipment		●	●	●	●	●	
C3 PLURIEL VAN	CD player			●	●	●	●	●	
C3 PLURIEL VAN	Parking aid			●	●	●	●	●	
C3 PLURIEL VAN	Air conditioning			●	●	●	●	●	
C3 PLURIEL VAN	Navigation			●	●	●	●	●	
C3 PLURIEL VAN	Alarm			●	●	●	●	●	
C3 PLURIEL VAN	Switch module under the steering wheel			●	●	●	●		
C3 PLURIEL VAN	Rain sensor/ Brightness				●	●			
C3 PLURIEL VAN	Sun roof			●			●	●	
C3 PLURIEL VAN	Driving school mode			●			●	●	
C3 PLURIEL VAN	Airbag			●	●	●	●		
C3 PLURIEL VAN	Display or Telematics	Multifunction display SAGEM A		●	●	●	●	●	
C3 PLURIEL VAN	Display or Telematics	Multifunction display SIEMENS B		●	●	●	●	●	
C3 PLURIEL VAN	Display or Telematics	Multifunction display SIEMENS C		●	●	●	●	●	
C3 PLURIEL VAN	Display or Telematics	Telematics unit		●	●	●	●	●	
C3 PLURIEL VAN	Gearbox ECU			●	●	●	●	●	
C3 PLURIEL VAN	Electric power steering ECU			●	●	●	●		
C3 PLURIEL VAN	Injection	Petrol engine	NFU BOSCH ME744	●	●	●	●	●	
C3 PLURIEL VAN	Injection	Petrol engine	KFV SAGEM S2000PM1		●	●		●	
C3 PLURIEL VAN	Injection	Petrol engine	KFV SAGEM S2000PM1		●	●		●	
C3 PLURIEL VAN	Injection	Petrol engine	KFV SAGEM S2000PM2		●	●			
C3 PLURIEL VAN	Injection	Diesel engine	8HZ BOSCH EDC16C34 DV4TD	●	●	●	●	●	
C3 PLURIEL VAN	Injection	Diesel engine	8HX SIEMENS SID802	●	●	●	●	●	
C3 PLURIEL VAN	Injection	Diesel engine	8HX SIEMENS SID804	●	●	●	●	●	
C3 PLURIEL VAN	Injection	Diesel engine	8HX SIEMENS SID804		●	●		●	

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
C3 PLURIEL VAN	Injection	Diesel engine	8HZ SIEMENS SID804	●	●	●	●	●	
C3 PLURIEL VAN	Injection	Diesel engine	8HZ SIEMENS SID804		●	●		●	
C3 PLURIEL VAN	Anti-lock brake system	ABS		●	●	●	●	●	
C3 PLURIEL VAN	Anti-lock brake system	ESP		●	●	●	●	●	05001
C3 R	BSI			●	●	●	●	●	03005
C3 R	Instrument panel			●	●	●	●	●	
C3 R	Radio			●	●	●	●	●	
C3 R	CD player			●	●	●	●	●	
C3 R	Parking aid			●	●	●	●	●	
C3 R	Air conditioning			●	●	●	●	●	
C3 R	Alarm			●	●	●	●	●	
C3 R	Switch module under the steering wheel	Top of column		●	●	●	●	●	
C3 R	Rain sensor/ Brightness			●	●	●			
C3 R	Airbag			●	●	●	●		
C3 R	Driving school mode			●	●	●		●	
C3 R	Multifunction screen	Multifunction screen A		●	●	●	●		
C3 R	Multifunction screen	Multifunction screen C		●	●	●	●	●	
C3 R	Telematic	Telematics (RT3)		●	●	●	●	●	
C3 R	Telematic	Telematic (RT4)		●	●	●	●	●	
C3 R	Telematic	Telematic (RT5)		●	●	●	●		
C3 R	High frequency receiver			●	●	●	●		
C3 R	Gas injection	SAX500 GPL			●	●		●	
C3 R	Gas injection	SAX500 GNV			●	●		●	
C3 R	Multiplexed diesel additive pump			●	●	●	●	●	
C3 R	Trailer relay unit			●	●	●	●	●	
C3 R	Engine relay unit			●	●	●	●	●	
C3 R	Gearbox ECU	Auto gearbox AL4		●	●	●	●	●	
C3 R	Gearbox ECU	Controlled manual gearbox ECU		●	●	●	●	●	
C3 R	Electric power steering ECU			●	●	●	●		
C3 R	Hands Free Kit			●	●	●	●	●	
C3 R	ECU Reversible "Stop-Start" alternator			●	●	●	●	●	
C3 R	Injection	Petrol engine	TU1A J34P	●	●	●	●	●	07001
C3 R	Injection	Petrol engine	TU3A J34P	●	●	●	●	●	07001
C3 R	Injection	Petrol engine	KFU MM6LPC	●	●	●	●	●	07003
C3 R	Injection	Petrol engine	NFS BOSCH ME745	●	●	●	●	●	
C3 R	Injection	Petrol engine	NFU BOSCH ME745	●	●	●	●	●	
C3 R	Injection	Petrol engine	N6A BOSCH ME745	●	●	●	●	●	
C3 R	Injection	Petrol engine	NFR BOSCH ME745	●	●	●	●	●	
C3 R	Injection	Petrol engine	KFV SAGEM S2000PM2		●	●			
C3 R	Injection	Diesel engine	8HZ BOSCH EDC16C34 DV4TD	●	●	●	●	●	
C3 R	Injection	Diesel engine	9HZ (FAP) BOSCH EDC16C34 DV6TED4	●	●	●	●	●	

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
C3 R	Injection	Diesel engine	9HX BOSCH EDC16C34 DV6ATED4	●	●	●	●	●	
C3 R	Injection	Diesel engine	8HZ SIEMENS SID806	●	●	●	●	●	
C3 R	Anti-lock brake system	ABS MK70		●	●	●	●	●	
C3 R	Anti-lock brake system	ABS MK70.1		●	●	●	●	●	
C3 R	Anti-lock brake system	ESP MK60		●	●	●	●	●	05001
C3 R	Anti-lock brake system	ESP MK60-0		●	●	●	●	●	
C4	BSI			●	●	●	●	●	03005
C4	Instrument panel			●	●	●	●	●	
C4	Radio	Radio post-equipment		●	●	●	●	●	
C4	CD player			●	●	●	●	●	
C4	Parking aid			●	●	●	●	●	
C4	Air conditioning			●	●	●	●	●	
C4	Lane departure warning system			●	●	●	●	●	
C4	Alarm			●	●	●	●	●	
C4	Steering wheel with fixed central controls			●	●	●	●	●	
C4	Multiplexed diesel additive pump			●	●	●	●	●	
C4	Driver's door module			●	●	●	●	●	
C4	Passenger's door module			●	●	●	●	●	
C4	Hi-Fi amplifier	Audio amplifier		●	●	●	●	●	
C4	Rain sensor/ Brightness			●	●	●	●	●	
C4	Driving school mode			●	●	●	●	●	
C4	Unit Rev counter	Rev counter		●	●	●	●	●	
C4	Driver's seat memorising unit			●	●	●	●	●	
C4	Airbag			●	●	●	●	●	
C4	Multifunction screen	Multifunction screen SAGEM A		●	●	●	●	●	
C4	Multifunction screen	Multifunction screen SAGEM C		●	●	●	●	●	
C4	Telematic	Telematics (RT3)		●	●	●	●	●	
C4	Telematic	Telematic (RT4)		●	●	●	●	●	
C4	Telematic	Telematic (RT5)		●	●	●	●	●	
C4	Telematic	RNEG navigation radio		●	●	●	●	●	
C4	Telematic	RASTREADOR		●	●	●	●	●	
C4	High frequency receiver			●	●	●	●	●	
C4	Trailer relay unit				●	●	●	●	
C4	Engine relay unit				●	●	●	●	
C4	Gearbox ECU		Auto gearbox AL4	●	●	●	●	●	
C4	Gearbox ECU		Auto gearbox AM6	●	●	●	●	●	
C4	Gearbox ECU		CFC300P	●	●	●	●	●	
C4	Gearbox ECU		BVA AM6 Euro5	●	●	●	●	●	
C4	Power steering		Electric pump unit (GEP)	●	●	●	●	●	
C4	Directional headlamps			●	●	●	●	●	

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
C4	Deflation detection			●	●	●	●		02003 02009 02010 02012
C4	Hands Free Kit	Mobile Housing		●	●	●	●	●	
C4	Diesel additive function			●	●	●	●	●	04008
C4	Injection	Petrol engine	5FT MED17.4	●	●	●	●	●	07002
C4	Injection	Petrol engine	5FX MED17.4	●	●	●	●	●	07002
C4	Injection	Petrol engine	RFN MM6LP	●	●	●	●	●	07001
C4	Anti-lock brake system	ESP8.1 BOSCH		●	●	●	●	●	05007
C4	Anti-lock brake system	ESP8 BOSCH		●	●	●		●	05002
C4	Injection	Petrol engine	RFK MM6LP	●	●	●	●	●	07001
C4	Injection	Petrol engine	KFU MM6LP	●	●	●	●	●	07001
C4	Injection	Petrol engine	RFJ MM6LPB		●	●		●	07001
C4	Injection	Petrol engine	6FY MM6LPB		●	●		●	07001
C4	Injection	Petrol engine	MM6KP		●	●		●	07001
C4	Injection	Petrol engine	NFU BOSCH ME745	●	●	●	●	●	
C4	Injection	Petrol engine	N6A BOSCH ME745	●	●	●	●	●	
C4	Injection	Petrol engine	NFS BOSCH ME745	●	●	●	●	●	
C4	Injection	Petrol engine	NFR BOSCH ME745	●	●	●	●	●	
C4	Injection	Petrol engine	NFU BOSCH ME749	●	●	●	●	●	
C4	Injection	Petrol engine	N6A BOSCH ME749	●	●	●	●	●	
C4	Injection	Petrol engine	MED17.4	●	●	●	●	●	07002
C4	Injection	Petrol engine	MEV17.4	●	●	●	●	●	07002
C4	Injection	Petrol engine	EDC16C3	●	●	●	●	●	
C4	Injection	Petrol engine	EDC15C2	●	●	●	●	●	
C4	Injection	Petrol engine	MM6LPC	●	●	●	●	●	
C4	Anti-lock brake system	ABS8.1 BOSCH		●	●	●	●	●	
C4	Anti-lock brake system	ABS8 BOSCH			●	●	●	●	
C4	Injection	Diesel engine	RHR DELPHI DCM3.4	●	●	●	●	●	
C4	Injection	Diesel engine	RHF DELPHI DCM3.4	●	●	●	●	●	
C4	Injection	Diesel engine	9HV BOSCH EDC16C34 DV6TED4	●	●	●	●	●	
C4	Injection	Diesel engine	9HX BOSCH EDC16C34 DV6ATED4	●	●	●	●	●	
C4	Injection	Diesel engine	9HZ (FAP) BOSCH EDC16C34 DV6TED4	●	●	●	●	●	
C4	Injection	Diesel engine	9HY BOSCH EDC16C34 DV6TED4	●	●	●	●	●	
C4	Injection	Diesel engine	RHR SIEMENS SID803A		●	●		●	04008 04010
C4	Injection	Diesel engine	RHR SIEMENS SID803		●	●		●	04001 04008 04010
C4	Injection	Diesel engine	DCM3.5	●	●	●	●	●	
C4	Electric secondary brake		FSE	●	●	●	●	●	
C4	Automatic gearbox electric control		COMELBVA	●	●	●	●	●	
C4	Pneumatic suspension		SUSPENSION	●	●	●	●	●	
C4 PICASSO	BSI			●	●	●	●	●	03005
C4 PICASSO	Instrument panel			●	●	●	●	●	
C4 PICASSO	Radio	Radio post-equipment		●	●	●	●	●	
C4 PICASSO	CD player			●	●	●	●	●	

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
C4 PICASSO	Parking aid			●	●	●	●	●	
C4 PICASSO	Air conditioning			●	●	●	●	●	
C4 PICASSO	Lane departure warning system			●	●	●	●	●	
C4 PICASSO	Steering wheel with fixed central controls			●	●	●	●	●	
C4 PICASSO	Alarm			●	●	●	●	●	
C4 PICASSO	Windscreen wiper			●	●	●	●	●	
C4 PICASSO	Additive pump	Multiplexed diesel additive pump		●	●	●	●	●	
C4 PICASSO	Additive pump	Additive pump		●	●	●	●	●	
C4 PICASSO	Driver's door module			●	●	●	●	●	
C4 PICASSO	Passenger's door module			●	●	●	●	●	
C4 PICASSO	Hi-Fi amplifier	Audio amplifier		●	●	●		●	
C4 PICASSO	Rain sensor/ Brightness			●	●	●			
C4 PICASSO	Driver's seat memorising unit			●	●	●	●	●	
C4 PICASSO	Airbag			●	●	●	●		
C4 PICASSO	Telematic	Telematics (RT3)		●	●	●	●	●	
C4 PICASSO	Telematic	Telematic (RT4)		●	●	●	●	●	
C4 PICASSO	Telematic	Telematic (RT5)		●	●	●	●		
C4 PICASSO	Telematic	RNEG navigation radio		●	●	●	●		
C4 PICASSO	High frequency receiver			●	●	●	●		
C4 PICASSO	Gearbox ECU	Auto gearbox AL4		●	●	●	●	●	
C4 PICASSO	Gearbox ECU	Auto gearbox AM6		●	●	●	●	●	
C4 PICASSO	Gearbox ECU	CFC300P		●	●	●	●	●	
C4 PICASSO	Gearbox ECU	BVA AM6 Euro5		●	●	●	●	●	
C4 PICASSO	Automatic gearbox electric control			●	●	●	●	●	
C4 PICASSO	Pneumatic suspension	Suspension		●	●	●	●	●	
C4 PICASSO	Power steering	Electric power steering ECU		●	●	●	●	●	
C4 PICASSO	Directional headlamps			●	●	●	●	●	
C4 PICASSO	Trailer relay unit				●	●	●	●	
C4 PICASSO	Engine relay unit				●	●		●	
C4 PICASSO	Deflation detection			●	●	●	●		02003 02007 02008 02009 02010 02012
C4 PICASSO	Electric secondary brake			●	●	●	●	●	01001 01005 01006
C4 PICASSO	Hands Free Kit	Mobile Housing		●	●	●	●	●	
C4 PICASSO	Battery charge status unit			●	●	●	●		
C4 PICASSO	Ambient interior lighting unit			●	●	●	●		
C4 PICASSO	ABS/ Electronic stability program		ESP8. 1_BOSCH	●	●	●	●	●	01002 01003 01004 01008 05007
C4 PICASSO	ABS/ Electronic stability program		ABS8 BOSCH	●	●	●	●	●	

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
C4 PICASSO	ABS/ Electronic stability program		ESP8 BOSCH	●	●	●	●	●	
C4 PICASSO	ABS/ Electronic stability program		ABS81	●	●	●	●	●	
C4 PICASSO	Injection/ Ignition	Petrol engine	5FT MED17.4	●	●	●	●	●	07002
C4 PICASSO	Injection/ Ignition	Petrol engine	5FX MED17.4	●	●	●	●	●	07002
C4 PICASSO	Injection/ Ignition	Petrol engine	MEV17.4	●	●	●	●	●	07002
C4 PICASSO	Injection/ Ignition	Petrol engine	MEV174	●	●	●	●	●	07002
C4 PICASSO	Injection/ Ignition	Petrol engine	MED174	●	●	●	●	●	07002
C4 PICASSO	Injection/ Ignition	Petrol engine	MEV17 4 2	●	●	●	●	●	07002
C4 PICASSO	Injection/ Ignition	Petrol engine	MED17 4 2	●	●	●	●	●	07002
C4 PICASSO	Injection/ Ignition	Petrol engine	RFJ MM6LPB	●	●	●	●	●	
C4 PICASSO	Injection/ Ignition	Petrol engine	6FY MM6LPB	●	●	●	●	●	
C4 PICASSO	Injection/ Ignition	Petrol engine	EDC15C2	●	●	●	●	●	
C4 PICASSO	Injection/ Ignition	Petrol engine	ME745	●	●	●	●	●	
C4 PICASSO	Injection/ Ignition	Petrol engine	ME749	●	●	●	●	●	
C4 PICASSO	Injection/ Ignition	Petrol engine	MM6KP	●	●	●	●	●	
C4 PICASSO	Injection/ Ignition	Diesel engine	9HZ (FAP) BOSCH EDC16C34 DV6TED4	●	●	●	●	●	
C4 PICASSO	Injection/ Ignition	Diesel engine	RHR SIEMENS SID803A		●	●		●	04008 04010
C4 PICASSO	Injection/ Ignition	Diesel engine	RHJ SIEMENS SID803A		●	●		●	04008 04010
C4 PICASSO	Injection/ Ignition	Diesel engine	RHE DCM3.5	●	●	●	●	●	
C4 PICASSO	Injection/ Ignition	Diesel engine	RHH DCM3.5	●	●	●	●	●	
C4 PICASSO	Injection/ Ignition	Diesel engine	RHD DCM3.5	●	●	●	●	●	
C4 PICASSO	Injection/ Ignition	Diesel engine	DCM35 BR2	●	●	●	●	●	
C4 PICASSO	Injection/ Ignition	Diesel engine	DCM3.4	●	●	●	●	●	
C4 PICASSO	Injection/ Ignition	Diesel engine	EDC16C3	●	●	●	●	●	
C4 SEDAN	BSI			●	●	●	●	●	03005
C4 SEDAN	Instrument panel			●	●	●	●	●	
C4 SEDAN	Radio	Radio post-equipment		●	●	●	●	●	
C4 SEDAN	CD player			●	●	●	●	●	
C4 SEDAN	Parking aid			●	●	●	●	●	
C4 SEDAN	Air conditioning			●	●	●	●	●	
C4 SEDAN	Switch module under the steering wheel			●	●	●	●	●	
C4 SEDAN	Alarm			●	●	●	●	●	
C4 SEDAN	Driver's seat memorising unit			●	●	●	●	●	
C4 SEDAN	Driver's door module			●	●	●	●	●	
C4 SEDAN	Passenger's door module			●	●	●	●	●	
C4 SEDAN	Unit Rev counter	Rev counter		●	●	●	●	●	
C4 SEDAN	Rain sensor/ Brightness			●	●	●	●	●	
C4 SEDAN	Airbag			●	●	●	●	●	
C4 SEDAN	Multifunction screen		Multifunction screen A	●	●	●	●	●	
C4 SEDAN	Multifunction screen		Multifunction screen C	●	●	●	●	●	
C4 SEDAN	Telematic		Telematics (RT3)	●	●	●	●	●	
C4 SEDAN	Telematic		Telematic (RT4)	●	●	●	●	●	

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
C4 SEDAN	Telematic		Telematic(RT5)	●	●	●	●		
C4 SEDAN	Trailer relay unit				●	●	●	●	
C4 SEDAN	Engine relay unit				●	●		●	
C4 SEDAN	Multiplexed diesel additive pump			●	●	●	●	●	
C4 SEDAN	Power steering	Electric pump unit(GEP)		●	●	●	●	●	
C4 SEDAN	Directional headlamps			●	●	●	●	●	
C4 SEDAN	Hands Free Kit			●	●	●	●	●	
C4 SEDAN	Injection	Petrol engine	RFJ MM6KP Bio Flex (EW10A FF)	●	●	●	●	●	
C4 SEDAN	Injection	Petrol engine	RFJ MM6KP (EW10A FF)	●	●	●	●	●	07001
C4 SEDAN	Injection	Petrol engine	RFJ MM6LPB	●	●	●	●	●	
C4 SEDAN	Injection	Petrol engine	NFU BOSCH ME749	●	●	●	●	●	
C4 SEDAN	Injection	Petrol engine	N6A BOSCH ME749	●	●	●	●	●	
C4 SEDAN	Injection	Petrol engine	NFS BOSCH ME745	●	●	●	●	●	
C4 SEDAN	Auto gearbox		BVA AL4 AT8	●	●	●	●	●	07001
C4 SEDAN	Auto gearbox		BVA AM6 AT6 EURO5	●	●	●	●	●	
C4 SEDAN	Auto gearbox		BVA AM6	●	●	●	●	●	
C4 SEDAN	Auto gearbox		CFC300P	●	●	●	●	●	
C4 SEDAN	ABS		ESP8.1 BOSCH	●	●	●	●	●	05007
C4 SEDAN	ABS		ESP8 BOSCH	●	●	●		●	05002
C4 SEDAN	Injection	Petrol engine	NFU BOSCH ME745	●	●	●	●	●	
C4 SEDAN	Injection	Petrol engine	N6A BOSCH ME745	●	●	●	●	●	
C4 SEDAN	Injection	Petrol engine	NFR BOSCH ME745	●	●	●	●	●	
C4 SEDAN	Injection	Petrol engine	EDC16C3	●	●	●	●	●	
C4 SEDAN	Injection	Petrol engine	MED17 4 EURO4	●	●	●	●	●	
C4 SEDAN	Injection	Petrol engine	MEV17 4 EURO4	●	●	●	●	●	
C4 SEDAN	Injection	Diesel engine	RHM BOSCH EDC15C2 DW10A	●	●	●	●	●	
C4 SEDAN	Injection	Diesel engine	RHM BOSCH EDC15C2 DW10A	●	●	●	●	●	
C4 SEDAN	Injection	Diesel engine	RHS BOSCH EDC15C2 DW10A	●	●	●	●	●	
C4 SEDAN	Injection	Diesel engine	RHS BOSCH EDC15C2 DW10A	●	●	●	●	●	
C4 SEDAN	Injection	Diesel engine	RHT BOSCH EDC15C2 DW10A	●	●	●	●	●	
C4 SEDAN	Injection	Diesel engine	RHT BOSCH EDC15C2 DW10A	●	●	●	●	●	
C4 SEDAN	Injection	Diesel engine	RHW BOSCH EDC15C2 DW10A	●	●	●	●	●	
C4 SEDAN	Injection	Diesel engine	RHW BOSCH EDC15C2 DW10A	●	●	●	●	●	
C4 SEDAN	Injection	Diesel engine	RHZ BOSCH EDC15C2 DW10A	●	●	●	●	●	
C4 SEDAN	Injection	Diesel engine	RHZ BOSCH EDC15C2 DW10A	●	●	●	●	●	
C4 SEDAN	Injection	Diesel engine	9HZ (FAP) BOSCH EDC16C34 DV6TED4-110CV	●	●	●	●	●	
C4 SEDAN	Injection	Diesel engine	9HX BOSCH EDC16C34 DV6ATED4- 90CV	●	●	●	●	●	
C4 SEDAN	Injection	Diesel engine	HDI SID803A	●	●	●	●	●	
C4 SEDAN	Injection	Diesel engine	DCM3.4	●	●	●	●	●	
C4 SEDAN	Injection	Diesel engine	DCM3.5	●	●	●	●	●	
C4 SEDAN	Injection	Diesel engine	HDI SID803	●	●	●	●	●	
C4 SEDAN	ABS		ABS8.1 BOSCH	●	●	●	●	●	
C4 SEDAN	ABS		ABS8 BOSCH		●	●	●	●	

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
C4 SEDAN	Electric secondary brake		FSE	●	●	●	●	●	
C4 SEDAN	Automatic gearbox electric control		COMELBVA	●	●	●	●	●	
C4 SEDAN	Pneumatic suspension		SUSPENSION	●	●	●	●	●	
C4 SEDAN	Under inflation detection		DSG	●	●	●	●	○	
C4Aircross	Injection/ignition		MIVEC	●	●	●	●	●	
C4Aircross	Injection/ignition		CMM 4A92	●	●	●	●	●	
C4Aircross	Injection/ignition		HDI 4N13	●	●	●	●	●	
C4Aircross	Injection/ignition		HDI SID807 J3J4	●	●	●	●	●	
C4Aircross	ABS/traction control		ABS 4x4	●	●	●	●	●	
C4Aircross	ABS/traction control		ESP 4x4	●	●	●	●	●	05006 05008
C4Aircross	Parking aid			●	●	●	●	○	
C4Aircross	Driver and passenger airbags			●	●	●	●	●	
C4Aircross	Driver's door module			●	●	●	●	○	
C4Aircross	Rain and brightness sensor			●	●	●	●	○	
C4Aircross	Anti-theft alarm			●	●	●	●	●	
C4Aircross	Power steering			●	●	●	●	○	
C4Aircross	Instrument panel			●	●	●	●	●	
C4Aircross	Starting authorisation ECU			●	●	●	●	●	
C4Aircross	Radio or radiotelephone(radio part)			●	●	●	●	●	
C4Aircross	Rear final drive piloted clutch			●	●	●	●	●	
C4Aircross	Directional headlamps			●	●	●	●	●	
C4Aircross	Locking and immobiliser control module		WCM	●	●	●	●	○	
C4Aircross	Locking and immobiliser control module		KOS	●	●	●	●	○	
C4Aircross	Calculateur stop and start			●	●	●	●	○	
C4Aircross	Streeing wheel angle sensor			●	●	●	●	●	05007
C4Aircross	Heating/ventilation			●	●	●	●	●	
C4Aircross	Gearbox		BV CVT	●	●	●	●	○	
C4Aircross	Navigation			●	●	●	●	○	
C5	BSI			●	●	●	●	●	03007 03008 03009
C5	BSI			●	●	●	●	●	03007 03008 03009
C5	Navigation	Navigation SIEMENS		●	●	●	●		
C5	Navigation	Navigation VDO		●			●		
C5	Instrument panel			●	●	●	●	●	
C5	Air conditioning			●	●	●	●	●	
C5	Radio post-equipment			●	●	●	●	●	
C5	Car-phone			●	●	●	●	●	
C5	Car-phone			●	●	●	●	●	
C5	CD player			●	●	●	●	●	
C5	Parking aid			●	●	●	●	●	
C5	Sun roof			●	●	●	●	●	
C5	Alarm			●	●	●	●	●	

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
C5	Switch module at the steering wheel	Top of column			●	●			
C5	Driver's door module			●			●		
C5	Passenger's door module			●			●		
C5	Airbag			●	●	●			
C5	Display or Autopc or Telematics	Multifunction display SAGEM A		●	●	●	●	●	
C5	Display or Autopc or Telematics	Multifunction display SAGEM B		●	●	●	●	●	
C5	Display or Autopc or Telematics	Multifunction display SIEMENS C		●	●	●	●	●	
C5	Display or Autopc or Telematics	Multifunction display VDO D		●	●	●	●	●	
C5	Display or Autopc or Telematics	Multifunction display AUTOPC		●	●	●	●	●	
C5	Display or Autopc or Telematics	Telematics unit		●	●	●	●	●	
C5	Diesel additive function	ADDITIF FAP		●	●	●	●	●	04008
C5	Diesel additive function	ADDGO2		●	●	●	●	●	04008
C5	Injection	Petrol engine	2.0L RFN MM48P	●	●	●	●	●	07001
C5	Injection	Petrol engine	RFN MM6LP	●	●	●	●	●	07001
C5	Suspension	Suspension		●	●	●	●	●	
C5	Suspension	ECOTECH SUSPENSION			●	●		●	
C5	Auto gearbox	Auto gearbox AL4		●			●	●	07001
C5	Auto gearbox	Auto gearbox 4HP20		●	●	●	●	●	07001
C5	Auto gearbox	Auto gearbox 4HP20		●	●	●	●	●	07001
C5	Auto gearbox	BVA ZF		●	●	●	●	●	07001
C5	additional heating			●	●	●	●	●	
C5	Right-hand headlamp			●	●	●		●	
C5	Left-hand headlamp			●	●	●		●	
C5	Injection	Petrol engine	RFN MM6LP	●	●	●	●	●	
C5	Injection	Petrol engine	3.0L XFX BOSCH ME746	●	●	●	●	●	
C5	Injection	Petrol engine	1.8L 6FZ SAGEM S2000P	●			●	●	
C5	Injection	Petrol engine	1.8L 6FZ SAGEM S2000P	●			●	●	
C5	Injection	Petrol engine	6FZ SAGEM S2000PM1		●	●		●	
C5	Injection	Petrol engine	6FZ SAGEM S2000PM1		●	●		●	
C5	Anti-lock brake system	ABS		●			●	●	
C5	Anti-lock brake system	ESP		●	●	●	●	●	
C5	Injection	Petrol engine	2.0L RLZ SIEMENS	●	●	●	●	●	
C5	Injection	Diesel engine	2.2 L 4HX BOSCH EDC15C2	●	●	●	●	●	04007
C5	Injection	Diesel engine	2.2 L 4HX BOSCH EDC15C2	●	●	●	●	●	04007
C5	Injection	Diesel engine	2.0 L RHY BOSCH EDC15C2	●	●	●	●	●	04007
C5	Injection	Diesel engine	2.0 L RHY BOSCH EDC15C2	●	●	●	●	●	04007
C5	Injection	Diesel engine	2.0 L RHZ BOSCH EDC15C2	●	●	●	●	●	04007
C5	Injection	Diesel engine	2.0 L RHZ BOSCH EDC15C2	●	●	●	●	●	04007
C5	Injection	Diesel engine	2.0 L RHS BOSCH EDC15C2	●	●	●	●	●	04007
C5	Injection	Diesel engine	2.0 L RHS BOSCH EDC15C2	●	●	●	●	●	04007

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
C5	Injection	Diesel engine	RHY SIEMENS SID801	●	●	●	●	●	
C5	Injection	Diesel engine	RHY SIEMENS SID801		●	●		●	
C5 (X7)	Anti-lock brake system	ESP8.1 BOSCH		●	●	●	●	●	01002 01004 01008 05007 07005
C5 (X7)	Injection	Petrol engine	MED17_4_EURO5	●	●	●	●	●	07002 08027 08053 08063 08054 08057 08056 08050 08059 08060 07005 08051 08061 08064 08062
C5 (X7)	Injection	Petrol engine	RFJ MM6KP (EW10A)	●	●	●	●	●	07001 07005 08068 07058 08027 08053 08050 08051 08052 08069
C5 (X7)	Injection	Petrol engine	RFJ MM6KP Bio Flex (EW10A FF)	●	●	●	●	●	07001 07005 08068 07058 08027 08053 08050 08051 08052 08069
C5 (X7)	Injection	Petrol engine	6FY MM6KP (EW7A)	●	●	●	●	●	07001 07005 08068 07058 08027 08053 08050 08051 08052 08069
C5 (X7)	Injection	Petrol engine	XFU BOSCH ME747	●	●	●	●	●	07005 07018 08027 08028 08029 07004 08050 08051 08052
C5 (X7)	Injection	Petrol engine	XFV BOSCH ME747	●	●	●	●	●	07005 07018 08027 08028 08029 07004 08050 08051 08052
C5 (X7)	Injection	Petrol engine	MEV17_4_2	●	●	●	●	●	08027 08053 08054 08055 08029 08050 08065 08060 07005 08051 08062 08066 08067 07057 08065
C5 (X7)	Injection	Petrol engine	MED17_4_2	●	●	●	●	●	08027 08053 08054 08055 07057 08056 08029 08057 07004 08050 08058 08059 08060 07005 08051 08061 08062
C5 (X7)	Injection	Diesel engine	9HZ (FAP) BOSCH EDC16C34 DV6TED4-110CV	●	●	●	●	●	
C5 (X7)	Injection	Diesel engine	4HP BOSCH EDC16CP39 DW12BTED4	●	●	●	●	●	08000 04006 07055 04002 08006 08007 08008 08009 08010 08011 07050 07011 04012 08012 04011 07010
C5 (X7)	Injection	Diesel engine	4HR BOSCH EDC16CP39 DW12BTED4	●	●	●	●	●	08000 04006 07055 04002 08006 08007 08008 08009 08010 08011 07050 07011 04012 08012 04011 07010
C5 (X7)	Injection	Diesel engine	4HS BOSCH EDC16CP39 DW12BTED4	●	●	●	●	●	08000 04006 07055 04002 08006 08007 08008 08009 08010 08011 07050 07011 04012 08012 04011 07010
C5 (X7)	Injection	Diesel engine	4HT BOSCH EDC16CP39 DW12BTED4	●	●	●	●	●	08000 04006 07055 04002 08006 08007 08008 08009 08010 08011 07050 07011 04012 08012 04011 07010
C5 (X7)	Injection	Diesel engine	UHZ SIEMENS SID201	●	●	●	●	●	04001 08070 07010 07011 04006 07055 07005 07018 04011 04012 08071

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
C5 (X7)	Injection	Diesel engine	RHR DELPHI DCM3.4	●	●	●	●	●	07005 07006 07007 07008 07009 07010 07011 04002 07012 07013 07014 07015 07016 04009 07018 07019 07020 07021 07022 07023 07050 04011 07051 07052 07053 07054 04006 07055 04012
C5 (X7)	Injection	Diesel engine	RHF DELPHI DCM3.4	●	●	●	●	●	07005 07006 07007 07008 07009 07010 07011 04002 07012 07013 07014 07015 07016 04009 07018 07019 07020 07021 07022 07023 07050 04011 07051 07052 07053 07054 04006 07055 04012
C5 (X7)	Injection	Diesel engine	RHH DCM3.5	●	●	●	●	●	04006 07007 07014 07015 07016 07017 07055 04002 04011 04012 04009 07082 07083 07084 07085 07086 07019 07020 07021 07022 07023 07010 07053 07006 07051 07052 07050 04012 04002 07087 07088 07089
C5 (X7)	Injection	Diesel engine	RHE DCM3.5	●	●	●	●	●	04006 07007 07014 07015 07016 07017 07055 04002 04011 04012 04009 07082 07083 07084 07085 07086 07019 07020 07021 07022 07023 07010 07053 07006 07051 07052 07050 04012 04002 07087 07088 07089
C5 (X7)	Injection	Diesel engine	X8Z-DT20C EDC17CP11	●	●	●	●	●	07090 07087 07089 07050 04012 07011
C5 (X7)	Injection	Diesel engine	DCM35_BR2	●	●	●	●	●	07006 07087 07090 07056 07091 07057 07007 07014 07015 07016 07017 04002 04003 04005 07082 07083 07084 07085 07086 07005 04009 07019 07020 07021 07022 07023 07050 07092 07093 04011 07059 07051 07094 07095 07052 07089 04012 07053
C5 (X7)	Injection	Diesel engine	DCM34_P	●	●	●	●	●	07006 07056 07057 07007 07005 07010 04002 04003 04006 07055 07014 07015 07016 07017 07018 04009 07019 07020 07021 07022 07023 07050 07058 04011 07059 07060 07052 04012 07081 07053
C5 (X7)	Injection	Diesel engine	EDC16C3	●	●	●	●	●	04006 07055 04012 07096 08000 07010 08001 08002 08003 07005 08004 08005 07018

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
C5 (X7)	Injection	Diesel engine	EDC17CP42	●	●	●	●	●	08013 07087 07053 08014 07095 07093 08015 07092 04011 07057 08016 07019 07020 07021 07022 07023 07007 07014 07015 07016 07017 08017 08018 07091 04005 04001 08019 04008 04002 07089 08020 08021 08022 07005
C5 (X7)	Injection	Siemens	HDI_SID807	●	●	●	●	●	07005 04006 07007 07014 07015 07016 07017 07083 07084 07085 07086 08023 07090 07087 07053 07006 07056 07091 07050 04012 04002 07089 04009
C5 (X7)	Injection	Siemens	HDI_SID807_BR2	●	●	●	●	●	07005 07007 07014 07015 07016 07017 04006 04009 07083 07084 07085 07086 07020 07021 07022 07023 07052 07080 07090 07094 07087 07053 07006 07056 07091 07050 04012 04002 07089 08024 07092 07095 07093 07057 08025 08026
C5 (X7)	Active damper electronic unit		BEBA	●	●	●	●	●	08073 08072 08074
C5 (X7)	BSI			●	●	●	●	●	03005
C5 (X7)	Instrument panel		COMBINE	●	●	●	●		08253 08254
C5 (X7)	Seat belt reminder LED			●				●	
C5 (X7)	Radio		AUTORADIO	●	●	●	●	●	08265 08266 08267 08268 08269
C5 (X7)	Radio		RD45	●	●	●	●	●	08265 08266 08267
C5 (X7)	CD player			●	●	●	●	●	
C5 (X7)	Parking aid		AIDE STAT	●	●	●	●	●	08264
C5 (X7)	Air conditioning			●	●	●	●	●	07005
C5 (X7)	Alarm			●	●	●	●	●	08081 08082 08083
C5 (X7)	Windscreen wiper	Wiper		●	●	●		●	
C5 (X7)	Driver's seat memorising unit			●	●	●	●	●	
C5 (X7)	Lane departure warning system		AFIL	●	●	●	●	●	07005 08255 08256 08257 08258
C5 (X7)	Steering wheel with fixed central controls			●	●	●	●	●	
C5 (X7)	Hi-Fi amplifier	Audio amplifier		●	●	●		●	07005
C5 (X7)	Rain sensor/ Brightness			●	●	●			
C5 (X7)	Airbag			●	●	●	●		08075 08076 08077 08078 08079 08080
C5 (X7)	Multifunction screen	Multifunction screen C	ECRAN C	●	●	●	●	●	08254 08263 08083
C5 (X7)	Multifunction screen		ECRAN A	●	●	●	●	●	08254 08263 08083
C5 (X7)	Telematic	Telematics (RT3)		●	●	●	●	●	
C5 (X7)	Telematic	Telematic (RT4)		●	●	●	●	●	
C5 (X7)	Telematic	Telematic (RT5)		●	●	●	●		

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
C5 (X7)	Telematic	RNEG navigation radio		●	●	●	●		
C5 (X7)	Telematic	NG4 navigation radio		●	●	●	●		
C5 (X7)	Gearbox ECU	Auto gearbox AL4		●	●	●	●	●	08084 08085 08086 07001
C5 (X7)	Gearbox ECU	Auto gearbox AM6		●	●	●	●	●	08087 08088 08089 08090 08091 07005 08092 08093 08094
C5 (X7)	Gearbox ECU	Auto gearbox AM6 Euro5		●	●	●	●	●	08088 08091 08089 08090 08087 07005 08094 08093
C5 (X7)	Gearbox ECU	CFC300P		●	●	●	●	●	08095 08096 08097 08098 08099 08200 08201 08202 08203 08204 08205 08206 08207 08208 08209 08210 08211 08212 08213
C5 (X7)	Suspension	ECOTECH SUSPENSION			●	●		●	08273 08274 07005
C5 (X7)	Suspension System Control ECU		CSS		●	●		●	08275
C5 (X7)	additional heating			●	●	●	●	●	
C5 (X7)	Trailer relay unit			●	●	●	●	●	
C5 (X7)	Engine relay unit			●	●	●	●	●	
C5 (X7)	Power steering	Electric pump unit(GEP)		●	●	●	●	●	
C5 (X7)	Directional headlamps		PROJECTEURS	●	●	●	●	●	07005 08214
C5 (X7)	Electric secondary brake			●	●	●	●	●	01005 01006
C5 (X7)	Hands Free Kit	Mobile Housing	BOITIER NOMADE	●	●	●	●	●	08250 08251
C5 (X7)	Hands Free Kit	Mobile Housing	KML	●	●	●	●	●	08252 08251
C5 (X7)	Driver's door control panel			●	●	●	●		
C5 (X7)	Battery charge status unit		BECEB GEN2	●	●	●	●		07005
C5 (X7)	Deflation detection			●	●	●	●		02003 02008 02009 02010 02012
C5 (X7)	Deflation detection		DSG UDS	●	●	●	●		
C5 (X7)	Motorised Boot ECU		BCOFFRE MOT	●	●	●	●		08259 08260 08261 08262
C5 (X7)	Services module		MD SERV	●	●	●	●	●	08270 08271 08272
C5 (X7)	Services module		BTA	●	●	●	●	●	08270 08271
C5 (X73C)	Anti-lock brake system	ESP8.1 BOSCH		●	●	●	●	●	01002 01004 01008 05007 07005
C5 (X73C)	Anti-theft alarm		ALARME	●	●	●	●	●	08082 08083 08081
C5 (X73C)	Air conditioning			●	●	●	●	●	07005
C5 (X73C)	Airbag			●	●	●	●		08075 08076 08077 08078 08079 08080
C5 (X73C)	Directional headlamps		PROJECTEURS	●	●	●	●	●	07005 08214
C5 (X73C)	Hi-Fi amplifier		Audio amplifier	●	●	●	●	●	07005
C5 (X73C)	Instrument panel		COMBINE	●	●	●	●		08253 08254
C5 (X73C)	Electric secondary brake		FSE						01005 01006
C5 (X73C)	Radio	AUTORADIO		●	●	●	●	●	08265 08266 08267 08268 08269
C5 (X73C)	Deflation detection			●	●	●	●		02003 02008 02009 02010 02012
C5 (X73C)	Multifunction screen	Multifunction screen C	ECRAN C	●	●	●	●	●	08254 08263 08083
C5 (X73C)	Gearbox ECU	Auto gearbox AL4		●	●	●	●	●	08084 08085 08086 07001
C5 (X73C)	Gearbox ECU	Auto gearbox AM6		●	●	●	●	●	08087 08088 08089 08090 08091 07005 08092 08093 08094
C5 (X73C)	Gearbox ECU	Auto gearbox AM6 Euro5		●	●	●	●	●	08088 08091 08089 08090 08087 07005 08094 08093
C5 (X73C)	Services module		MD SERV	●	●	●	●	●	08270 08271 08272

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
C5 (X73C)	Suspension	ECOTECH SUSPENSION			●	●		●	08273 08274 07005
C5 (X73C)	Suspension System Control ECU		CSS		●	●		●	08275
C5 (X73C)	Injection	Petrol engine	MM6KP	●	●	●	●	●	07001 07005 08068 07058 08027 08053 08050 08051 08052 08069
C5 (X73C)	Injection	Siemens	HDI_SID807	●	●	●	●	●	07005 04006 07007 07014 07015 07016 07017 07083 07084 07085 07086 08023 07090 07087 07053 07006 07056 07091 07050 04012 04002 07089 04009
C5 (X73C)	Injection	Petrol engine	ME747	●	●	●	●	●	07005 07018 08027 08028 08029 07004 08050 08051 08052
C5 R	Anti-lock brake system	ESP	ESP MK60		●	●		●	05001
C5 R	Diesel additive function			●	●	●	●	●	04008
C5 R	Injection	Petrol engine	RFJ MM6LPB		●	●		●	07001
C5 R	Injection	Petrol engine	6FY MM6LPB		●	●		●	07001
C5 R	Injection	Petrol engine	XFU BOSCH ME747	●	●	●	●	●	
C5 R	Injection	Petrol engine	XFV BOSCH ME747	●	●	●	●	●	
C5 R	Injection	Petrol engine	6FZ SAGEM S2000PM2		●	●		●	
C5 R	Injection	Diesel engine	4HP BOSCH EDC16CP39 DW12BTED4	●	●	●	●	●	
C5 R	Injection	Diesel engine	4HR BOSCH EDC16CP39 DW12BTED4	●	●	●	●	●	
C5 R	Injection	Diesel engine	4HS BOSCH EDC16CP39 DW12BTED4	●	●	●	●	●	
C5 R	Injection	Diesel engine	4HT BOSCH EDC16CP39 DW12BTED4	●	●	●	●	●	
C5 R	Injection	Diesel engine	2.2 L 4HX BOSCH EDC15C2	●	●	●	●	●	
C5 R	Injection	Diesel engine	2.2 L 4HX BOSCH EDC15C2	●	●	●	●	●	
C5 R	Injection	Diesel engine	9HY BOSCH EDC16C34 DV6TED4	●	●	●	●	●	
C5 R	Injection	Diesel engine	9HZ (FAP) BOSCH EDC16C34 DV6ATED4	●	●	●	●	●	
C5 R	Injection	Diesel engine	RHR SIEMENS SID803A		●	●		●	04008 04010
C5 R	Injection	Diesel engine	RHL SIEMENS SID803A		●	●		●	04008 04010
C5 R	Injection	Diesel engine	RHR SIEMENS SID803		●	●		●	04001 04008 04010
C5 R	Injection	Diesel engine	RHL SIEMENS SID803		●	●		●	04001 04008 04010
C5 R	BSI				●	●	●	●	03005
C5 R	Instrument panel				●	●		●	
C5 R	Radio	Radio post-equipment		●	●	●	●	●	
C5 R	CD player			●	●	●	●	●	
C5 R	Parking aid			●	●	●	●	●	
C5 R	Air conditioning			●	●	●	●	●	
C5 R	Lane departure warning system			●	●	●	●	●	
C5 R	Alarm			●	●	●	●	●	

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
C5 R	Switch module under the steering wheel	Top of column		●	●	●	●	●	
C5 R	Driver's door module			●	●	●	●	●	
C5 R	Passenger's door module			●	●	●	●	●	
C5 R	Rain sensor/ Brightness			●	●	●			
C5 R	Sun roof		TO WEBASTO		●	●		●	07001
C5 R	Airbag			●	●	●	●		
C5 R	Multifunction screen	Multifunction screen SAGEM A		●	●	●	●	●	
C5 R	Multifunction screen	Multifunction screen SAGEM C		●	●	●	●	●	
C5 R	Telematic	Telematics (RT3)		●	●	●	●	●	
C5 R	Telematic	Telematic (RT4)		●	●	●	●	●	
C5 R	Telematic	Telematic (RT5)		●	●	●	●		
C5 R	Trailer relay unit				●	●	●	●	
C5 R	Engine relay unit				●	●		●	
C5 R	Suspension	ECOTECH SUSPENSION			●	●		●	
C5 R	Gearbox ECU	Auto gearbox AL4		●	●	●	●	●	07001
C5 R	Gearbox ECU	Auto gearbox 4HP20		●	●	●	●	●	07001
C5 R	Gearbox ECU	Auto gearbox AM6		●	●	●	●	●	07001
C5 R	additional heating			●	●	●	●	●	
C5 R	Power steering	Electric pump unit(GEP)		●	●	●	●	●	
C5 R	Directional headlamps			●	●	●		●	
C5 R	Deflation detection			●	●	●	●	●	02003 02008 02009 02010 02012
C5 R	Hands Free Kit			●	●	●	●	●	
C6	Anti-lock brake system	ESP8.1 BOSCH		●	●	●	●	●	05007
C6	Anti-lock brake system	ESP VSC440			●	●		●	05003
C6	Anti-lock brake system	ESP VSC440			●	●		●	05003
C6	Injection	Petrol engine	XFU BOSCH ME747	●	●	●	●	●	
C6	Injection	Petrol engine	XFV BOSCH ME747	●	●	●	●	●	
C6	Injection	Diesel engine	4HP BOSCH EDC16CP39 DW12BTED4	●	●	●	●	●	
C6	Injection	Diesel engine	4HR BOSCH EDC16CP39 DW12BTED4	●	●	●	●	●	
C6	Injection	Diesel engine	4HS BOSCH EDC16CP39 DW12BTED4	●	●	●	●	●	
C6	Injection	Diesel engine	4HT BOSCH EDC16CP39 DW12BTED4	●	●	●	●	●	
C6	Injection	Diesel engine	UHZ SIEMENS SID201	●	●	●	●	●	04001
C6	Injection	Diesel engine	X8Z-DT20C EDC17CP11	●	●	●	●	●	
C6	BSI			●	●	●	●	●	03005
C6	Instrument panel				●	●		●	
C6	Radio	Radio post-equipment		●	●	●	●	●	
C6	CD player			●	●	●	●	●	
C6	Parking aid			●	●	●	●	●	
C6	Air conditioning			●	●	●	●	●	
C6	Rear air conditioning table				●	●			

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
C6	Lane departure warning system			●	●	●	●	●	
C6	Alarm			●	●	●	●	●	
C6	Windscreen wiper	Wiper		●	●	●		●	
C6	Switch module under the steering wheel	Top of column		●	●	●	●	●	
C6	LH seat switch panel				●	●		●	
C6	RH seat switch panel				●	●		●	
C6	Driver's door module				●	●			
C6	Passenger's door module				●	●			
C6	Rain sensor/ Brightness			●	●	●			
C6	Driver's seat memorising unit			●	●	●	●	●	
C6	Passenger's seat memorizing unit			●	●	●		●	
C6	Rear seat memorising unit				●	●			
C6	Airbag			●	●	●	●		
C6	Multifunction screen		Colour multifunction display	●	●	●	●		
C6	Multifunction screen		EMF A	●	●	●	●	●	
C6	Telematic	Telematics (RT3)		●	●	●	●	●	
C6	Telematic	Telematic (RT4)		●	●	●	●	●	
C6	Telematic	Telematic (RT5)		●	●	●	●		
C6	Suspension	ECOTECH SUSPENSION			●	●		●	
C6	Variable damping				●	●		●	
C6	Gearbox ECU	Auto gearbox AM6		●	●	●	●	●	
C6	Gearbox ECU	BVA AM6 Euro5		●	●	●	●	●	
C6	Pedestrian impact detection			●	●	●	●		
C6	Trailer relay unit				●	●	●	●	
C6	Engine relay unit				●	●		●	
C6	Boot relay unit				●	●		●	
C6	Boot moving deflector				●	●		●	
C6	additional heating			●	●	●	●	●	
C6	Power steering	Electric pump unit (GEP)		●	●	●	●	●	
C6	Directional headlamps			●	●	●	●	●	
C6	Headlamp beam corrector	LH headlamp beam corrector		●	●	●	●	●	
C6	Headlamp beam corrector	RH headlamp beam corrector		●	●	●	●		
C6	Deflation detection			●	●	●	●		02003 02008 02009 02010 02012
C6	Electric secondary brake			●	●	●	●	●	01007 01009
C6	Hands Free Kit	Mobile Housing		●	●	●	●	●	
C6	Battery charge status unit			●	●	●	●		
C6	High Head Vision			●	●	●	●		
C8 CAN	Anti-lock brake system	ESP8.1 BOSCH		●	●	●	●	●	
C8 CAN	Anti-lock brake system	ESP8 BOSCH		●	●	●		●	
C8 CAN	Diesel additive function			●	●	●	●	●	

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
C8_CAN	Injection	Petrol engine	RFJ MMGLPB	●	●	●	●	●	
C8_CAN	Injection	Diesel engine	4HP BOSCH EDC16CP39 DW12BTED4	●	●	●	●	●	
C8_CAN	Injection	Diesel engine	4HR BOSCH EDC16CP39 DW12BTED4	●	●	●	●	●	
C8_CAN	Injection	Diesel engine	4HS BOSCH EDC16CP39 DW12BTED4	●	●	●	●	●	
C8_CAN	Injection	Diesel engine	4HT BOSCH EDC16CP39 DW12BTED4	●	●	●	●	●	
C8_CAN	Injection	Diesel engine	2.2 L 4HW BOSCH EDC15C2	●	●	●	●	●	
C8_CAN	Injection	Diesel engine	2.2 L 4HW BOSCH EDC15C2	●	●	●	●	●	
C8_CAN	Injection	Diesel engine	2.0 L RHT BOSCH EDC15C2	●	●	●	●	●	
C8_CAN	Injection	Diesel engine	2.0 L RHT BOSCH EDC15C2	●	●	●	●	●	
C8_CAN	Injection	Diesel engine	2.0 L RHW BOSCH EDC15C2	●	●	●	●	●	
C8_CAN	Injection	Diesel engine	2.0 L RHW BOSCH EDC15C2	●	●	●	●	●	
C8_CAN	Injection	Diesel engine	2.0 L RHZ BOSCH EDC15C2	●	●	●	●	●	
C8_CAN	Injection	Diesel engine	2.0 L RHZ BOSCH EDC15C2	●	●	●	●	●	
C8_CAN	Injection	Diesel engine	2.0 L RHM BOSCH EDC15C2	●	●	●	●	●	
C8_CAN	Injection	Diesel engine	2.0 L RHM BOSCH EDC15C2	●	●	●	●	●	
C8_CAN	Injection	Diesel engine	RHR SIEMENS SID803A		●	●	●	●	
C8_CAN	Injection	Diesel engine	RHK SIEMENS SID803A		●	●	●	●	
C8_CAN	Injection	Diesel engine	DCM35 BR2	●	●	●	●	●	
C8_CAN	BSI			●	●	●	●	●	03005
C8_CAN	Instrument panel			●	●	●	●	●	
C8_CAN	Radio	Radio post-equipment		●	●	●	●	●	
C8_CAN	CD player			●	●	●	●	●	
C8_CAN	Parking aid			●	●	●	●	●	
C8_CAN	Air conditioning			●	●	●	●	●	
C8_CAN	LEDs and odometer ECU			●	●	●	●		
C8_CAN	Alarm			●	●	●	●	●	
C8_CAN	Switch module under the steering wheel	Top of column		●	●	●	●	●	
C8_CAN	Sliding side doors module			●	●	●	●	●	
C8_CAN	Driver's door module			●	●	●	●	●	
C8_CAN	Passenger's door module			●	●	●	●	●	
C8_CAN	Rain sensor/ Brightness			●	●	●			
C8_CAN	Front sunroof			●	●	●	●		
C8_CAN	Rear sunroof			●	●	●	●		
C8_CAN	Middle sunroof			●	●	●	●		
C8_CAN	Memory unit			●	●	●	●	●	
C8_CAN	Airbag			●	●	●	●		
C8_CAN	Telematic receiver command			●			●		
C8_CAN	Multifunction screen	Multifunction display SIEMENS C		●	●	●	●	●	
C8_CAN	Telematic	Telematics (RT3)		●	●	●	●	●	
C8_CAN	Telematic	Telematic (RT4)		●	●	●	●	●	
C8_CAN	Telematic	Telematic (RT5)		●	●	●	●		

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
C8 CAN	Telematic	RNEG navigation radio		●	●	●	●		
C8 CAN	Trailer relay unit			●	●	●	●	●	
C8 CAN	Engine relay unit			●	●	●	●	●	
C8 CAN	Gearbox ECU	Auto gearbox AL4		●	●	●	●	●	
C8 CAN	Gearbox ECU	Auto gearbox AM6		●	●	●	●	●	
C8 CAN	Gearbox ECU	BVA AM6 Euro5		●	●	●	●	●	
C8 CAN	additional heating			●	●	●	●	●	
C8 CAN	Power steering			●	●	●	●	●	
C8 CAN	Right-hand headlamp			●	●	●	●	●	
C8 CAN	Left-hand headlamp			●	●	●	●	●	
C8 CAN	Deflation detection			●	●	●	●		02003 02008 02009 02010 02012
C8 CAN	Hands Free Kit	Mobile Housing		●	●	●	●	●	
C8 VAN	Anti-lock brake system	ESP	ESP BOSCH5.7	●			●	●	05003
C8 VAN	Anti-lock brake system	ESP	ESP8 BOSCH	●			●	●	05003
C8 VAN	Anti-lock brake system	ESP	ESP8.1	●			●	●	05007
C8 VAN	Diesel additive function	ADDITIF FAP		●	●	●	●	●	04008
C8 VAN	Diesel additive function	ADDG02		●	●	●	●	●	04008
C8 VAN	Injection	Petrol engine	2.0L RFN MM48P	●	●	●	●	●	07001
C8 VAN	Injection	Petrol engine	3FZ MM4MP2	●	●	●	●	●	07001
C8 VAN	Injection	Petrol engine	RFN MM4MP2	●	●	●	●	●	07001
C8 VAN	Injection	Petrol engine	RFN MM6LP	●	●	●	●	●	
C8 VAN	Injection	Petrol engine	RFN MM6LP	●	●	●	●	●	
C8 VAN	Injection	Petrol engine	3FZ MM6LP	●	●	●	●	●	
C8 VAN	Injection	Petrol engine	3FZ MM6LP	●	●	●	●	●	
C8 VAN	Injection	Petrol engine	3.0L XFW BOSCH ME746	●	●	●	●	●	
C8 VAN	Injection	Diesel engine	2.2 L 4HW BOSCH EDC15C2	●	●	●	●	●	04007
C8 VAN	Injection	Diesel engine	2.2 L 4HW BOSCH EDC15C2	●	●	●	●	●	04007
C8 VAN	Injection	Diesel engine	2.0 L RHT BOSCH EDC15C2	●	●	●	●	●	04007
C8 VAN	Injection	Diesel engine	2.0 L RHT BOSCH EDC15C2	●	●	●	●	●	04007
C8 VAN	Injection	Diesel engine	2.0 L RHW BOSCH EDC15C2	●	●	●	●	●	04007
C8 VAN	Injection	Diesel engine	2.0 L RHW BOSCH EDC15C2	●	●	●	●	●	04007
C8 VAN	Injection	Diesel engine	2.0 L RHZ BOSCH EDC15C2	●	●	●	●	●	04007
C8 VAN	Injection	Diesel engine	2.0 L RHZ BOSCH EDC15C2	●	●	●	●	●	04007
C8 VAN	Injection	Diesel engine	2.0 L RHM BOSCH EDC15C2	●	●	●	●	●	04007
C8 VAN	BSI			●	●	●	●	●	03005
C8 VAN	Instrument panel			●	●	●	●	●	
C8_VAN	Radio or telematic receiver command	Radio post-equipment		●	●	●	●	●	
C8_VAN	Radio or telematic receiver command	Telematic receiver command		●			●		
C8 VAN	CD player			●	●	●	●	●	
C8 VAN	Parking aid			●	●	●	●	●	
C8 VAN	Air conditioning			●	●	●		●	
C8 VAN	LEDs and odometer ECU			●	●	●	●	●	
C8 VAN	Memory unit			●			●	●	
C8 VAN	Rear sunroof			●			●	●	
C8 VAN	Front sunroof			●			●	●	

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
C8 VAN	Middle sunroof			●			●	●	
C8 VAN	Alarm				●	●		●	
C8 VAN	Switch module at the steering wheel	Top of column			●	●			
C8 VAN	Sliding side doors module			●			●	●	
C8 VAN	Injection	Diesel engine	2.0 L RHM BOSCH EDC15C2	●	●	●	●	●	04007
C8 VAN	Airbag			●	●	●	●		
C8 VAN	Display or Telematics	Multifunction display SAGEM B		●	●	●	●	●	
C8 VAN	Display or Telematics	Telematics unit		●	●	●	●	●	
C8 VAN	Auto gearbox	Auto gearbox AL4		●			●	●	07001
C8 VAN	Auto gearbox	Auto gearbox AL4		●			●	●	07001
C8 VAN	Auto gearbox	Auto gearbox AL4		●			●	●	07001
C8 VAN	Auto gearbox	Auto gearbox 4HP20		●			●	●	07001
C8 VAN	Auto gearbox	Auto gearbox 4HP20		●			●	●	07001
C8 VAN	additional heating			●	●	●	●	●	
C8 VAN	Right-hand headlamp			●	●	●	●	●	
C8 VAN	Left-hand headlamp			●	●	●	●	●	
C-CROSSER	BSI				●	●	●	●	
C-CROSSER	Rear final drive piloted clutch				●	●	●	●	
C-CROSSER	Gearbox	Gearbox CVT			●	●	●		
C-CROSSER	Gearbox	BOITE GETRAG			●	●	●	●	
C-CROSSER	Steering wheel angle sensor				●	●			
C-CROSSER	Airbag				●	●	●	●	
C-CROSSER	Locking and immobiliser control module				●	●	●		
C-CROSSER	Instrument panel				●	●	●	●	03001 03002 03004 03005
C-CROSSER	Air conditioning				●	●	●	●	
C-CROSSER	Radio	Radio post-equipment			●	●	●	●	
C-CROSSER	Hands Free Kit				●	●	●	●	
C-CROSSER	Navigation				●	●			
C-CROSSER	Driver's door control panel				●	●			
C-CROSSER	Passenger's door switch panel				●	●			
C-CROSSER	Rear LH door switch panel				●	●			
C-CROSSER	Rear RH door switch panel				●	●			
C-CROSSER	Sun roof				●	●			
C-CROSSER	Gear lever(DCT)				●	●	●	●	
C-CROSSER	ABS/ Electronic stability program	ABS anti-lock braking system			●	●	●	●	
C-CROSSER	ABS/ Electronic stability program	Electronic stability program			●	●	●	●	
C-CROSSER	Injection/ Ignition	Petrol engine	SFZ MIVEC 2.4 L		●	●	●	●	
C-CROSSER	Injection/ Ignition	Diesel engine	4HN BOSCH EDC16CP39		●	●	●	●	04003
C-CROSSER	Parking aid		AAS MMC	●	●	●	●		
C-ELYSEE 4/C-ELYSEE 5	ABS			●	●	●	●	●	

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
C-ELYSEE 4/C-ELYSEE 5	Gearbox ECU			●			●	●	07001
C-ELYSEE 4/C-ELYSEE 5	Airbag				●	●	●		
C-ELYSEE 4/C-ELYSEE 5	Transponder			●			●		
C-ELYSEE 4/C-ELYSEE 5	Central locking control unit			●	●	●	●		
C-ELYSEE 4/C-ELYSEE 5	Injection	1.6 L NFU BOSCH ME744		●	●	●	●	●	
C-ELYSEE 4/C-ELYSEE 5	Injection	NFU J35			●	●		●	07003
C-QUATRE 4	BSI			●	●	●	●	●	03005
C-QUATRE 4	Instrument panel			●	●	●	●	●	
C-QUATRE 4	Radio			●	●	●	●	●	
C-QUATRE 4	CD player			●	●	●	●	●	
C-QUATRE 4	Parking aid			●	●	●	●	●	
C-QUATRE 4	Air conditioning			●	●	●	●	●	
C-QUATRE 4	Alarm			●	●	●	●	●	
C-QUATRE 4	Steering wheel with fixed central controls			●	●	●	●	●	
C-QUATRE 4	Airbag			●	●	●	●		
C-QUATRE 4	Multifunction screen			●	●	●	●		
C-QUATRE 4	Gearbox ECU			●	●	●	●	●	
C-QUATRE 4	Trailer relay unit				●	●	●	●	
C-QUATRE 4	Engine relay unit				●	●	●	●	
C-QUATRE 4	Power steering				●	●			
C-QUATRE 4	Hands Free Kit			●	●	●	●	●	
C-QUATRE 4	Driver's door module			●	●	●	●	●	
C-QUATRE 4	Passenger's door module			●	●	●	●	●	
C-QUATRE 4	Telematic	Telematics (RT3)		●	●	●	●	●	
C-QUATRE 4	Telematic	Telematic (RT4)		●	●	●	●	●	
C-QUATRE 4	ABS	ESP8.1 BOSCH		●	●	●	●	●	05007
C-QUATRE 4	ABS	ABS8.1 BOSCH		●	●	●	●	●	
C-QUATRE 4	Injection	RFJ MM6LPB		●	●	●	●	●	
C-QUATRE 4	Injection	N6A BOSCH ME745		●	●	●	●	●	
C-QUATRE 4	Injection	MM6KP		●	●	●	●	●	07001
C-QUATRE 5	BSI			●	●	●	●	●	03005
C-QUATRE 5	Instrument panel			●	●	●	●	●	
C-QUATRE 5	Radio			●	●	●	●	●	
C-QUATRE 5	CD player			●	●	●	●	●	
C-QUATRE 5	Parking aid			●	●	●	●	●	
C-QUATRE 5	Air conditioning			●	●	●	●	●	
C-QUATRE 5	Alarm			●	●	●	●	●	
C-QUATRE 5	Steering wheel with fixed central controls			●	●	●	●	●	
C-QUATRE 5	Rain sensor/ Brightness			●	●	●			
C-QUATRE 5	Airbag			●	●	●	●		
C-QUATRE 5	Multifunction screen			●	●	●	●	●	
C-QUATRE 5	Gearbox ECU			●	●	●	●	●	
C-QUATRE 5	Trailer relay unit				●	●	●	●	
C-QUATRE 5	Engine relay unit				●	●	●	●	

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
C-QUATRE 5	Power steering				●	●			
C-QUATRE 5	Hands Free Kit			●	●	●	●	●	
C-QUATRE 5	Driver's door module			●	●	●	●	●	
C-QUATRE 5	Passenger's door module			●	●	●	●	●	
C-QUATRE 5	Telematic	Telematics (RT3)		●	●	●	●	●	
C-QUATRE 5	Telematic	Telematic (RT4)		●	●	●	●	●	
C-QUATRE 5	ABS	ESP8.1 BOSCH		●	●	●	●	●	05007
C-QUATRE 5	ABS	ABS8.1 BOSCH		●	●	●	●	●	
C-QUATRE 5	Injection	RFJ MM6LPB		●	●	●	●	●	
C-QUATRE 5	Injection	N6A BOSCH ME745		●	●	●	●	●	
C-TRIOMPHE	BSI			●	●	●	●	●	03005
C-TRIOMPHE	Instrument panel			●	●	●	●	●	
C-TRIOMPHE	Radio			●	●	●	●	●	
C-TRIOMPHE	CD player			●	●	●	●	●	
C-TRIOMPHE	Parking aid			●	●	●	●	●	
C-TRIOMPHE	Air conditioning			●	●	●	●	●	
C-TRIOMPHE	Alarm			●	●	●	●	●	
C-TRIOMPHE	Steering wheel with fixed central controls			●	●	●	●	●	
C-TRIOMPHE	Rain sensor/ Brightness			●	●	●			
C-TRIOMPHE	Airbag			●	●	●	●		
C-TRIOMPHE	Multifunction screen			●	●	●	●	●	
C-TRIOMPHE	Gearbox ECU			●	●	●	●	●	
C-TRIOMPHE	Trailer relay unit				●	●	●	●	
C-TRIOMPHE	Engine relay unit				●	●		●	
C-TRIOMPHE	Power steering				●	●			
C-TRIOMPHE	Directional headlamps			●	●	●	●	●	
C-TRIOMPHE	Hands Free Kit			●	●	●	●	●	
C-TRIOMPHE	Driver's door module			●	●	●	●	●	
C-TRIOMPHE	Passenger's door module			●	●	●	●	●	
C-TRIOMPHE	Telematic	Telematics (RT3)		●	●	●	●	●	
C-TRIOMPHE	Telematic	Telematic (RT4)		●	●	●	●	●	
C-TRIOMPHE	ABS	ESP8.1 BOSCH		●	●	●	●	●	05007
C-TRIOMPHE	ABS	ESP8 BOSCH		●	●	●	●	●	05002
C-TRIOMPHE	ABS	ABS8.1 BOSCH		●	●	●	●	●	
C-TRIOMPHE	ABS	ABS8 BOSCH			●	●	●	●	
C-TRIOMPHE	Injection	Petrol engine	RFJ MM6LPB	●	●	●	●	●	
C-ZERO	Built-in System Interface			●	●	●	●	●	
C-ZERO	Electric motor ECU			●	●	●	●	●	
C-ZERO	Traction battery ECU			●	●	●	●	●	
C-ZERO	Electric vehicle management ECU			●	●	●	●	●	
C-ZERO	Traction battery cell electronics		CMU_01	●	○	○	●	○	
C-ZERO	Traction battery cell electronics		CMU_02	●	○	○	●	○	

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
C-ZERO	Traction battery cell electronics		CMU_03	●	○	○	●	○	
C-ZERO	Traction battery cell electronics		CMU_04	●	○	○	●	○	
C-ZERO	Traction battery cell electronics		CMU_05	●	○	○	●	○	
C-ZERO	Traction battery cell electronics		CMU_06	●	○	○	●	○	
C-ZERO	Traction battery cell electronics		CMU_07	●	○	○	●	○	
C-ZERO	Traction battery cell electronics		CMU_08	●	○	○	●	○	
C-ZERO	Traction battery cell electronics		CMU_09	●	○	○	●	○	
C-ZERO	Traction battery cell electronics		CMU_10	●	○	○	●	○	
C-ZERO	Traction battery cell electronics		CMU_11	●	○	○	●	○	
C-ZERO	Traction battery cell electronics		CMU_12	●	○	○	●	○	
C-ZERO	ESP			●	●	●	●	●	
C-ZERO	Power steering			●	●	●	●	○	
C-ZERO	Steering wheel angle sensor			●	●	●	●	●	05002 05005
C-ZERO	Airbag			●	●	●	●	●	
C-ZERO	Airbag		ORC	●	●	●	●	●	
C-ZERO	Gateway wiring housing			●	●	●	●	○	
C-ZERO	Independent telematic unit			●	●	●	●	●	
C-ZERO	Instrument panel			●	●	●	●	●	
C-ZERO	Radio			●	●	●	●	●	
C-ZERO	Air conditioning			●	●	●	●	●	
C-ZERO	Air conditioning compressor and passeger compartment heating control module			●	●	●	●	●	
DS3	Auto gearbox		BVA AL4	●	●	●	●	●	07001
DS3	Auto gearbox		MAPS UDS	●	●	●	●	●	
DS3	Auto gearbox		CFC300P	●	●	●	●	●	
DS3	Injection		MED17.4	●	●	●	●	●	07002
DS3	Injection		MEV174	●	●	●	●	●	07002
DS3	Injection		MEV17_4_2	●	●	●	●	●	07002
DS3	Injection		MED17_4_2	●	●	●	●	●	
DS3	Injection		EDC16C3	●	●	●	●	●	
DS3	Injection		HDI SID807_BR2	●	●	●	●	●	
DS3	Injection		V46	●	●	●	●	●	
DS3	Injection		EDC17C60	●	●	●	●	●	
DS3	ABS		ESPMK100	●	●	●	●	●	
DS4/C4 (B7)	ABS/traction control		ABS81	●	●	●	●	●	05001
DS4/C4 (B7)	ABS/traction control		81 ESP	●	●	●	●	●	01003 01008 05001

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
DS4/C4 (B7)	Instrument panel			●	●	●	●	●	
DS4/C4 (B7)	Display		EMF A UDS	●	●	●	●	●	
DS4/C4 (B7)	Display		EMF C UDS	●	●	●	●	○	
DS4/C4 (B7)	Trailer relay unit			●	●	●	●	●	
DS4/C4 (B7)	Driver's seat memorizing unit			●	●	●	●	●	
DS4/C4 (B7)	Steering wheel with integral controls (VCI)			●	●	●	●	●	
DS4/C4 (B7)	Parking aid			●	●	●	●	○	
DS4/C4 (B7)	audio amplifier			●	●	●	○	●	
DS4/C4 (B7)	Telematics		RADIONAV RNEG C	●	●	●	●	●	
DS4/C4 (B7)	Telematics		RNEG2010	●	●	●	●	●	
DS4/C4 (B7)	Matrix screen integral to the instrument panel		MATT_C_2010	●	●	●	○	●	
DS4/C4 (B7)	Matrix screen integral to the instrument panel		MATT_M_2010	●	●	●	○	●	
DS4/C4 (B7)	Driver's door module			●	●	●	●	●	
DS4/C4 (B7)	Switch module under the steering wheel		HDC	●	●	●	●	●	
DS4/C4 (B7)	Switch module under the steering wheel		COM2008P	●	●	●	●	●	
DS4/C4 (B7)	Lane departure warning system			●	●	●	●	●	
DS4/C4 (B7)	gearbox		BVA AL4	●	●	●	●	●	07004
DS4/C4 (B7)	gearbox		BVA AM6 AT6 EURO5	●	●	●	●	●	
DS4/C4 (B7)	gearbox		CFC300P	●	●	●	●	●	
DS4/C4 (B7)	Electric secondary brake			●	●	●	●	●	01001 01005 01006
DS4/C4 (B7)	Power steering electric pump unit			●	●	●	●	●	
DS4/C4 (B7)	Anti-theft alarm			●	●	●	●	●	
DS4/C4 (B7)	Under inflation detection			●	●	●	●	●	02001 02002 02003 02004 02009 02011 02012
DS4/C4 (B7)	Air conditioning ECU			●	●	●	●	●	
DS4/C4 (B7)	Rain sensor			●	●	●	●	○	
DS4/C4 (B7)	Radio			●	●	●	●	●	
DS4/C4 (B7)	Air-bag			●	●	●	●	○	
DS4/C4 (B7)	Seat belts not fastened LED unit			●	○	○	○	●	
DS4/C4 (B7)	Multiplexed control panel			●	●	●	●	●	
DS4/C4 (B7)	Monitoring of the blind spot			●	●	●	●	●	
DS4/C4 (B7)	Engine ECU		DCM35 BR2	●	●	●	●	●	04002 04005 04011 04012
DS4/C4 (B7)	Engine ECU		EDC17C10 BR2	●	●	●	●	●	04006
DS4/C4 (B7)	Engine ECU		HDI. SID807 BR2	●	●	●	●	●	04006 04012
DS4/C4 (B7)	Engine ECU		MEV17. 4. 2	●	●	●	●	●	07004
DS4/C4 (B7)	Engine ECU		MED17. 4. 2	●	●	●	●	●	07004
DS4/C4 (B7)	Engine ECU		ME745	●	●	●	●	●	

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
DS4/C4 (B7)	Engine ECU		MEVD17.4.2	●	●	●	●	●	07004
DS4/C4 (B7)	Discharge bulbs vertical and horizontal adjustment			●	●	●	●	●	
DS4/C4 (B7)	Engine relay unit			●	●	●	●	●	
DS4/C4 (B7)	Independent telematic unit (BTA)			●	●	●	●	●	
DS4/C4 (B7)	Multiplexed additive adding pump			●	●	●	●	●	
DS4/C4 (B7)	Battery charge status unit			●	●	●	●	○	
DS4/C4 (B7)	Driving school module			●	●	●	○	●	
DS4/C4 (B7)	Supply protection and management unit			●	●	●	●	○	
DS4/C4 (B7)	Voltage retaining device			●	○	○	○	○	
DS5	ABS/traction control			●	●	●	●	●	01003 01008 05001
DS5	Built-in Systems Interface			●	●	●	●	○	
DS5	Engine ECU		HDI SID807 BR2	●	●	●	●	●	04006 04012
DS5	Engine ECU		DCM35 HY	●	●	●	●	●	04005 04012
DS5	Engine ECU		DCM35 BR2	●	●	●	●	●	04005 04012
DS5	Engine ECU		MED17.4.2	●	●	●	●	●	
DS5	Engine ECU		MEVD17.4.2	●	●	●	●	●	
DS5	Gearbox		CFC300P HY	●	●	●	●	●	
DS5	gearbox		BVA AM6 AT6 EURO5	●	●	●	●	●	
DS5	Power steering electric pump unit			●	●	●	●	●	
DS5	Electric steering lock			●	●	●	●	●	
DS5	Multiplexed additive adding pump			●	●	●	●	●	
DS5	Service module		BTA	●	●	●	●	●	
DS5	Service module		BLVV	●	●	●	●	●	
DS5	Supply protection and management unit			●	●	●	●	○	
DS5	Battery charge status unit			●	●	●	●	○	
DS5	Telematic navigator			●	●	●	●	●	
DS5	Electric secondary brake			●	●	●	●	●	01001 01005 01006
DS5	Trailer relay unit			●	●	●	●	●	
DS5	Electronic key reader			●	●	●	●	○	
DS5	Seat belts not fastened LED unit (TNB)			●	○	○	○	●	
DS5	Instrument panel		COMBINE UDS	●	●	●	●	●	
DS5	Display		EMF_A	●	●	●	●	●	
DS5	Display		EMF_C	●	●	●	●	●	
DS5	Matrix screen integral to the instrument panel		COLOUR MATRIX SCREEN	●	●	●	●	●	
DS5	Matrix screen integral to the instrument panel		MONOCHROME MATRIX SCREEN	●	●	●	●	●	
DS5	Anti-theft alarm		Alarm with anti-lift module	●	●	●	●	●	

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
DS5	Vibrators control ECU			●	●	●	●	●	
DS5	Switch module under the steering wheel (top of column)			●	●	●	●	●	
DS5	Hands-free control unit			●	●	●	●	○	
DS5	Rain sensor			●	●	●	●	○	
DS5	Hybrid mode selector			●	●	●	●	●	
DS5	Traction battery ECU			●	●	●	●	●	
DS5	Hybrid control ECU 1			●	●	●	●	●	
DS5	Hybrid control ECU 2			●	●	●	●	○	
DS5	Under inflation detection (DSG)			●	●	●	●	●	02001 02002 02003 02004 02009 02011 02012
DS5	Parking aid			●	●	●	●	○	
DS5	Driver's seat memorizing unit			●	●	●	●	●	
DS5	Voltage retaining device			●	○	○	○	○	
DS5	High head Vision			●	●	●	●	●	
DS5	Multifunction camera or multifunction video camera			●	●	●	●		
DS5	Air conditioning			●	●	●	●	●	
DS5	audio amplifier			●	●	●	●	●	
DS5	Discharge bulbs vertical and horizontal adjustment			●	●	●	●	●	
DS5	Air-bag		RBG UDS	●	●	●	●	○	
DS5	Engine relay unit			●	●	●	●	●	
DS5	Telematics		RADIONAV RNEG C	●	●	●	●	●	
DS5	Telematics		RNEG 2010	●	●	●	●	●	
DS5	Radio			●	●	●	●	●	
DS5	Steering wheel with integral controls(VCI)			●	●	●	●	●	
DS5	Multiplexed control panel			●	●	●	●	●	
DS5	Clock			●	●	●	●	●	
DS5	Windscreen wiper			●	●	●	●	●	
ELYSEE	Transponder			●			●		
ELYSEE	Gearbox ECU	Auto gearbox AL4 TA96		●			●		
ELYSEE	Gearbox ECU	Auto gearbox AL4 TA2000		●			●	●	07001
ELYSEE	Gearbox ECU	Auto gearbox AL4 TA2000		●			●	●	07001
ELYSEE	Gearbox ECU	Auto gearbox AL4 TA2000		●			●	●	07001
ELYSEE	Airbag	Airbag		●					
ELYSEE	Airbag	Sac SIEMENS			●	●	●		
ELYSEE	Anti-lock brake system			●			●	●	
ELYSEE	Injection	1.6 L NFU BOSCH ME744		●	●	●	●	●	
EVASION	Injection	Diesel engine	2.1 L P8C LUCAS EPIC	●			●	●	
FUKANG/FUKANG 988	Gearbox ECU	Auto gearbox AL4 TA96		●			●		
FUKANG/FUKANG 988	Gearbox ECU	Auto gearbox AL4 TA2000		●			●	●	07001
FUKANG/FUKANG 988	Gearbox ECU	Auto gearbox AL4 TA2000		●			●	●	07001
FUKANG/FUKANG 988	Gearbox ECU	Auto gearbox AL4 TA2000		●			●	●	07001

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
FUKANG/FUKANG 988	Transponder			●			●		
FUKANG/FUKANG 988	Injection	1.6 L NFU BOSCH ME744		●	●	●	●	●	
FUKANG/FUKANG 988	Anti-lock brake system	ABS Bosch 5.3		●			●	●	
FUKANG/FUKANG 988	Anti-lock brake system	ABS8.1 BOSCH		●	●	●	●	●	
JUMPER	Injection	Petrol engine	2.0 L RFN MM48P	●	●	●	●	●	07001
JUMPER 3	Injection/ ignition	Diesel engine	EDC16C39 SOFIM 3.0 145		●	●	●	●	
JUMPER 3	Injection/ ignition	Diesel engine	EDC16C39 SOFIM 3.0 145 CV FAP		●	●	●	●	
JUMPER 3	Injection/ ignition	Diesel engine	DCU-102 4HU PUMA 120 CV		●	●	●	●	
JUMPER 3	Injection/ ignition	Diesel engine	DCU-102 4HV PUMA 100 CV		●	●	●	●	
JUMPER 3	ABS/ Electronic stability program	ESP8_BOSCH			●	●	●	●	
JUMPER 3	Built-in Systems Interface (BSI)						●	●	
JUMPER 3	Instrument panel			●	●	●	●	●	※
JUMPER 3	Parking aid			●	●	●	●	●	
JUMPER 3	Air conditioning			●	●	●	●	●	
JUMPER 3	Telematic	Telematic		●	●	●	●	●	
JUMPER 3	Chrono-tachograph			●	●	●	●	●	
JUMPER 3	ABS/ Electronic stability program	ABS8_BOSCH			●	●	●	●	
JUMPER 3	ABS/ Electronic stability program	ASR8.0			●	●	●	●	
JUMPER 3	Airbags			●			●	●	
JUMPER 3	Power steering				●	●	●	●	
JUMPER 3	Pneumatic suspension	Suspension			●	●	●	●	
JUMPER 3	additional heating				●	●	●	●	
JUMPER 3 Minibus	Injection/ ignition	Diesel engine	EDC16C39 SOFIM 3.0 145		●	●	●	●	
JUMPER 3 Minibus	Injection/ ignition	Diesel engine	EDC16C39 SOFIM 3.0 145 CV FAP		●	●	●	●	
JUMPER 3 Minibus	Injection/ ignition	Diesel engine	DCU-102 4HU PUMA 120 CV		●	●	●	●	
JUMPER 3 Minibus	Injection/ ignition	Diesel engine	DCU-102 4HV PUMA 100 CV		●	●	●	●	
JUMPER 3 Minibus	Built-in Systems Interface (BSI)						●	●	
JUMPER 3 Minibus	Instrument panel			●	●	●	●	●	※
JUMPER 3 Minibus	Parking aid			●	●	●	●	●	
JUMPER 3 Minibus	Air conditioning			●	●	●	●	●	
JUMPER 3 Minibus	Telematic	Telematic		●	●	●	●	●	
JUMPER 3 Minibus	Chrono-tachograph			●	●	●	●	●	
JUMPER 3 Minibus	Airbags			●			●	●	
JUMPER 3 Minibus	Power steering				●	●	●	●	
JUMPER 3 Minibus	Pneumatic suspension	Suspension			●	●	●	●	
JUMPER 3 Minibus	additional heating				●	●	●	●	
JUMPY	Auto gearbox			●			●	●	07001
JUMPY	Auto gearbox			●			●	●	07001
JUMPY	Auto gearbox			●			●	●	07001
JUMPY	additional heating			●	●	●	●	●	

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
JUMPY	Injection	Petrol engine	2.0 L RFN MM48P	●	●	●	●	●	07001
JUMPY	Injection	Diesel engine	2.0 L RHW BOSCH EDC15C2	●	●	●	●	●	
JUMPY	Injection	Diesel engine	2.0 L RHW BOSCH EDC15C2	●	●	●	●	●	
JUMPY	Injection	Diesel engine	2.0 L RHZ BOSCH EDC15C2	●	●	●	●	●	
JUMPY	Injection	Diesel engine	2.0 L RHZ BOSCH EDC15C2	●	●	●	●	●	
JUMPY	Injection	Diesel engine	2.0 L RHX BOSCH EDC15C2	●	●	●	●	●	
JUMPY	Injection	Diesel engine	2.0 L RHX BOSCH EDC15C2	●	●	●	●	●	
JUMPY	Injection	Diesel engine	1.9 L WJY LUCAS DCN2	●	●	●	●	●	
JUMPY 2	Auto gearbox	Auto gearbox AL4		●			●	●	07001
JUMPY 2	Auto gearbox	Auto gearbox AL4		●			●	●	07001
JUMPY 2	Auto gearbox	Auto gearbox AL4		●			●	●	07001
JUMPY 2	additional heating			●	●	●	●	●	
JUMPY 2	Airbag			●	●	●			
JUMPY 2	Injection	Petrol engine	2.0 L RFN MM48P	●	●	●	●	●	07001
JUMPY 2	Injection	Diesel engine	2.0 L RHW BOSCH EDC15C2	●	●	●	●	●	
JUMPY 2	Injection	Diesel engine	2.0 L RHZ BOSCH EDC15C2	●	●	●	●	●	
JUMPY 2	Injection	Diesel engine	2.0 L RHX BOSCH EDC15C2	●	●	●	●	●	
JUMPY 2	Injection	Diesel engine	1.9 L WJY LUCAS DCN2	●	●	●	●	●	
JUMPY 2	Anti-lock brake system	ABS electronic distribution		●			●	●	
JUMPY 3	BSI			●	●	●	●	●	03005
JUMPY 3	Instrument panel			●	●	●	●		
JUMPY 3	Radio	Radio post-equipment		●	●	●	●	●	
JUMPY 3	CD player			●	●	●	●	●	
JUMPY 3	Parking aid			●	●	●	●	●	
JUMPY 3	Air conditioning			●	●	●	●	●	
JUMPY 3	Rear air conditioning table			●	●	●	●		
JUMPY 3	Switch module under the steering wheel	Top of column		●	●	●	●	●	
JUMPY 3	Alarm			●	●	●	●	●	
JUMPY 3	Rain sensor/ Brightness			●	●	●			
JUMPY 3	Airbag			●	●	●	●		
JUMPY 3	Multifunction screen	Multifunction screen A		●	●	●	●	●	
JUMPY 3	Multifunction screen	Multifunction screen C		●	●	●	●	●	
JUMPY 3	Telematic	Telematics (RT3)		●	●	●	●	●	
JUMPY 3	Telematic	Telematic (RT4)		●	●	●	●	●	
JUMPY 3	Telematic	Telematic (RT5)		●	●	●	●		
JUMPY 3	Telematic	RNEG navigation radio		●	●	●	●		
JUMPY 3	Power steering	Electric power steering ECU		●	●	●	●	●	
JUMPY 3	Pneumatic suspension	Suspension		●	●	●	●	●	
JUMPY 3	additional heating			●	●	●	●	●	
JUMPY 3	Trailer relay unit			●	●	●	●	●	
JUMPY 3	Engine relay unit			●	●	●	●	●	
JUMPY 3	Hands Free Kit	Mobile Housing		●	●	●	●	●	
JUMPY 3	Bodywork Conversion Unit			●	●	●	●	●	
JUMPY 3	Injection/ Ignition	Petrol engine	RFH MM6KP	●	●	●	●	●	07001

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
JUMPY 3	Injection/ Ignition	Diesel engine	9HU BOSCH EDC16C34 DV6UTD4 - 90CV	●	●	●	●	●	
JUMPY 3	Injection/ Ignition	Diesel engine	RHR SIEMENS SID803A		●	●		●	04008 04010
JUMPY 3	Injection/ Ignition	Diesel engine	RHK SIEMENS SID803A		●	●		●	04008 04010
JUMPY 3	Injection/ Ignition	Diesel engine	RHG SIEMENS SID803A		●	●		●	04008 04010
JUMPY 3	ABS/ Electronic stability program	ABS8.1_BOSCH		●	●	●	●	●	
JUMPY 3	ABS/ Electronic stability program	ABS8_BOSCH			●	●		●	
JUMPY 3	ABS/ Electronic stability program	ESP8_BOSCH		●	●	●		●	05002
JUMPY 3	ABS/ Electronic stability program	ESP8.1_BOSCH		●	●	●	●	●	05007
NEMO	BSI			●			●	●	
NEMO	Gearbox	Gearbox BVMP MAP		●	●	●	●		
NEMO	Driver's and passenger's airbags	Airbag		●	●	●	●	●	
NEMO	Instrument panel			●	●	●	●	●	※
NEMO	Parking aid			●	●	●	●		
NEMO	Injection/ Ignition	Petrol engine	KFV V34P	●	●	●	●	●	07003
NEMO	Injection/ Ignition	Petrol engine	V34.2	●	●	●	●	●	07003
NEMO	Injection/ Ignition	Diesel engine	8HS BOSCH EDC16C34	●	●	●	●		04004
NEMO	Injection/ Ignition	Diesel engine	HDI 8DF2	●	●	●	●	●	
NEMO	Injection/ Ignition	Diesel engine	HDI 8DF3	●	●	●	●	●	
NEMO	Anti-lock Braking System (ABS) / Electronic Stability Program (ESP)	ABS		●	●	●	●	●	
SAXO	Electrical vehicle	Electric motor		●				●	
SAXO	additional heating			●	●	●	●	●	
SAXO	Transponder	Transponder VALEO		●			●		
SAXO	Injection	Petrol engine	1.0 L CDY/CDZ BOSCH	●			●		
SAXO	Injection	Petrol engine	1.1 L HDY/HDZ BOSCH	●			●		
SAXO	Injection	Petrol engine	1.1 L HFX BOSCH M7.4.4	●	●	●	●	●	
SAXO	Injection	Petrol engine	1.4 L KFW SAGEM S2000	●			●	●	07001
SAXO	Injection	Petrol engine	1.4 L KFW SAGEM S2000	●			●	●	
SAXO	Injection	Petrol engine	1.4 L KFX MM1AP	●			●		
SAXO	Injection	Petrol engine	1.4 L KFX BOSCH MP7.3	●			●	●	
SAXO	Injection	Petrol engine	1.6 L NFX MM48P	●	●	●	●	●	07001
SAXO	Injection	Petrol engine	1.6 L NFT BOSCH M7.4.4	●	●	●	●	●	07001
SAXO	Injection	Petrol engine	1.6 L NFX MM1AP	●			●		
SAXO	Injection	Petrol engine	1.6 L NFZ BOSCH MP7.2	●			●	●	
SAXO	Injection	Diesel engine	1.5L VJX/VJU BOSCH AS4-VP20	●			●	●	
SAXO	Anti-lock brake system	ABS		●			●		
XANTIA 2	Injection	Petrol engine	1.8 L LFX MM1AP				●		
XANTIA 2	Injection	Petrol engine	1.8 L LFY SAGEM SL96	●			●	●	
XANTIA 2	Injection	Petrol engine	1.8 L LFY BOSCH MP7.3	●			●	●	

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
XANTIA 2	Injection	Petrol engine	3.0 L Xfz BOSCH MP7.0	●			●	●	
XANTIA 2	Injection	Diesel engine	2.1 L P8C LUCAS EPIC	●			●	●	
XANTIA 2	Injection	Diesel engine	2.0 L RHZ BOSCH EDC15C2	●			●	●	
XANTIA 2	Injection	Diesel engine	2.0 L RHZ BOSCH EDC15C2	●			●	●	
XANTIA 2	Injection	Diesel engine	2.0 L RHZ BOSCH EDC15C2	●	●	●	●	●	
XANTIA 2	Injection	Diesel engine	2.0 L RHY BOSCH EDC15C2	●			●	●	
XANTIA 2	Injection	Diesel engine	2.0 L RHY BOSCH EDC15C2	●			●	●	
XANTIA 2	Injection	Diesel engine	2.0 L RHY BOSCH EDC15C2	●	●	●	●	●	
XANTIA 2	additional heating			●	●	●	●	●	
XANTIA 2	Right hand side airbag			●				●	
XANTIA 2	Left hand side airbag			●				●	
XANTIA 2	Auto gearbox	Auto gearbox ZF 4HP20		●			●		
XANTIA 2	Auto gearbox	Auto gearbox AL4		●			●		07001
XM/XM MULTIPLEXEE	Injection	2.1 L P8C LUCAS EPIC		●			●	●	
XSARA	Injection	Petrol engine	1.4 L KFX MM1AP	●			●		
XSARA	Injection	Petrol engine	1.4 L KFX BOSCH MP7.3	●			●	●	
XSARA	Injection	Petrol engine	1.4L KFX SAGEM SL96	●			●	●	
XSARA	Injection	Petrol engine	1.6 L NFZ BOSCH MP7.2	●			●	●	
XSARA	Injection	Petrol engine	1.8 L LFX MM1AP	●			●		
XSARA	Injection	Petrol engine	1.8L Lfy SAGEM SL96	●			●	●	
XSARA	Injection	Petrol engine	2.0 L RFS MM1AP	●			●		
XSARA	Injection	Diesel engine	2.0 L RHY BOSCH EDC15C2	●	●	●	●	●	
XSARA	Injection	Petrol engine	1.4 L KFX BOSCH MP7.3	●			●	●	
XSARA	Injection	Petrol engine	1.4L KFX SAGEM SL96	●			●	●	
XSARA	Injection	Petrol engine	1.6 L NFZ BOSCH MP7.2	●			●	●	
XSARA	Injection	Petrol engine	1.8 L LFX MM1AP	●			●		
XSARA	Injection	Petrol engine	1.8L Lfy SAGEM SL96	●			●	●	
XSARA	Injection	Petrol engine	2.0 L RFS MM1AP	●			●		
XSARA	Injection	Diesel engine	2.0 L RHY BOSCH EDC15C2	●			●	●	
XSARA	additional heating			●	●	●	●	●	
XSARA	Anti-lock brake system	ABS mechanical distribution		●			●	●	
XSARA	Airbag			●					
XSARA	Airbag			●					
XSARA	Left hand side airbag			●				●	
XSARA	Right hand side airbag			●				●	
XSARA	BSI			●			●	●	
XSARA	Radio post-equipment			●			●	●	
XSARA	CD player			●			●	●	
XSARA	Instrument panel			●				●	
XSARA	additional heating			●	●	●	●	●	
XSARA	Anti-lock brake system	ABS electronic distribution		●			●	●	
XSARA	Anti-lock brake system	ABS mechanical distribution		●			●	●	
XSARA	Airbag			●					

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
XSARA	Left hand side airbag			●				●	
XSARA	Right hand side airbag			●				●	
XSARA	Auto gearbox	Auto gearbox AL4		●			●		07001
XSARA	Anti-lock brake system	ABS electronic distribution		●			●	●	
XSARA 2	BSI			●			●	●	
XSARA 2	Navigation			●	●	●	●	●	
XSARA 2	Instrument panel			●			●	●	
XSARA 2	Air conditioning			●	●	●	●	●	
XSARA 2	Radio post-equipment			●	●	●	●	●	
XSARA 2	CD player			●			●	●	
XSARA 2	Parking aid			●			●	●	
XSARA 2	Top of column				●	●			
XSARA 2	Alarm				●	●		●	
XSARA 2	Driving school mode			●			●	●	
XSARA 2	Display or Autopc	Multifunction display A		●	●	●	●	●	
XSARA 2	Display or Autopc	Multifunction display B		●	●	●	●	●	
XSARA 2	Display or Autopc	Multifunction display C		●	●	●	●	●	
XSARA 2	Display or Autopc	AUTOPC		●	●	●		●	
XSARA 2	Auto gearbox	Auto gearbox AL4		●			●	●	07001
XSARA 2	Airbag			●	●	●			
XSARA 2	BSI			●			●	●	03007 03008 03009
XSARA 2	Navigation			●	●	●	●	●	
XSARA 2	Instrument panel			●			●	●	
XSARA 2	Air conditioning			●	●	●	●	●	
XSARA 2	Radio post-equipment			●	●	●	●	●	
XSARA 2	Car-phone			●	●	●	●	●	
XSARA 2	CD player			●			●	●	
XSARA 2	Parking aid			●			●	●	
XSARA 2	Switch module at the steering wheel	Top of column			●	●			
XSARA 2	Alarm				●	●		●	
XSARA 2	Driving school mode			●			●	●	
XSARA 2	Rain sensor/ Brightness				●	●			
XSARA 2	Airbag			●	●	●			
XSARA 2	Injection	Petrol engine	2.0L RFN MM48P	●	●	●	●	●	07001
XSARA 2	Injection	Petrol engine	2.0L RFS MM48P	●	●	●	●	●	07001
XSARA 2	Injection	Petrol engine	RFN MM4MP2	●	●	●	●	●	07001
XSARA 2	Injection	Petrol engine	1.6L NFU BOSCH ME744	●	●	●	●	●	
XSARA 2	Injection	Petrol engine	1.4L KFW SAGEM S2000P	●			●	●	
XSARA 2	Injection	Diesel engine	2.0 L RHY BOSCH EDC15C2	●	●	●	●	●	
XSARA 2	Injection	Diesel engine	2.0 L RHZ BOSCH EDC15C2	●	●	●	●	●	
XSARA 2	Injection	Diesel engine	1.9L WJY LUCAS DCN2	●	●	●	●	●	
XSARA 2	Injection	Diesel engine	RHY SIEMENS SID801	●	●	●	●	●	
XSARA 2	Injection	Diesel engine	8HZ BOSCH EDC16C3 (DV4)		●	●			
XSARA 2	Injection	Petrol engine	RFN MM6LP	●	●	●	●	●	

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
XSARA 2	Anti-lock brake system	ABS electronic distribution		●			●	●	
XSARA 2	Anti-lock brake system	ESP	ESP BOSCH5.7	●			●	●	05003
XSARA PICASSO	Injection	Petrol engine	1.6L NFZ BOSCH MP7.2	●			●	●	
XSARA PICASSO	Injection	Petrol engine	1.6L NFV BOSCH M744	●	●	●	●	●	
XSARA PICASSO	Injection	Petrol engine	2.0L RFM MM48P	●	●	●	●	●	07001
XSARA PICASSO	Injection	Petrol engine	1.8L 6FZ SAGEM S2000P	●			●	●	
XSARA PICASSO	Injection	Petrol engine	6FZ SAGEM S2000PM1		●	●		●	
XSARA PICASSO	Injection	Petrol engine	6FZ SAGEM S2000PM2		●	●			
XSARA PICASSO	Injection	Petrol engine	NFS BOSCH ME745	●	●	●	●	●	
XSARA PICASSO	BSI ECU			●			●		
XSARA PICASSO	Navigation			●	●	●	●		
XSARA PICASSO	Multifunction display	Multifunction display VDO B		●	●	●	●	●	
XSARA PICASSO	Multifunction display	Multifunction display VDO C		●	●	●	●	●	
XSARA PICASSO	Air conditioning			●	●	●	●	●	
XSARA PICASSO	Radio post-equipment			●	●	●	●	●	
XSARA PICASSO	CD player			●	●	●	●	●	
XSARA PICASSO	Instrument panel			●	●	●	●	●	
XSARA PICASSO	Injection	Petrol engine	NFU BOSCH ME745	●	●	●	●	●	
XSARA PICASSO	Injection	Petrol engine	N6A BOSCH ME745	●	●	●	●	●	
XSARA PICASSO	Injection	Petrol engine	NFR BOSCH ME745	●	●	●	●	●	
XSARA PICASSO	Injection	Diesel engine	2.0 L BOSCH EDC15C2	●	●	●	●	●	
XSARA PICASSO	Diesel additive function			●	●	●	●	●	04008
XSARA PICASSO	Additional heating			●	●	●	●	●	
XSARA PICASSO	Airbag			●					
XSARA PICASSO	Left hand side airbag			●				●	
XSARA PICASSO	Right hand side airbag			●				●	
XSARA PICASSO	Anti-lock brake system	ABS electronic distribution		●			●	●	05003
XSARA PICASSO	Anti-lock brake system	ESP		●	●	●	●	●	05003
XSARA PICASSO CHINE	BSI			●	●	●	●	●	03005
XSARA PICASSO CHINE	Navigation				●	●			
XSARA PICASSO CHINE	Air conditioning			●	●	●	●	●	
XSARA PICASSO CHINE	Instrument panel			●	●	●	●	●	
XSARA PICASSO CHINE	Radio post-equipment			●	●	●	●	●	
XSARA PICASSO CHINE	CD player			●	●	●	●	●	
XSARA PICASSO CHINE	Parking aid			●	●	●	●	●	
XSARA PICASSO CHINE	Alarm				●	●		●	
XSARA PICASSO CHINE	Switch module at the steering wheel	Top of column			●	●			
XSARA PICASSO CHINE	Rain sensor/ Brightness				●	●			
XSARA PICASSO CHINE	Airbag			●	●	●			
XSARA PICASSO CHINE	Multifunction display	Multifunction display SAGEM B		●	●	●	●	●	

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
XSARA PICASSO CHINE	Multifunction display	Multifunction display SIEMENS C		●	●	●	●	●	
XSARA PICASSO CHINE	Telematic	RASTREADOR		●	●	●	●		
XSARA PICASSO CHINE	Auto gearbox	Auto gearbox AL4		●			●	●	07001
XSARA PICASSO CHINE	additional heating			●	●	●	●	●	
XSARA PICASSO CHINE	Diesel additive function			●	●	●	●	●	04008
XSARA PICASSO CHINE	Injection	Petrol engine	RFN MM6LP	●	●	●	●	●	
XSARA PICASSO CHINE	Injection	Petrol engine	6FZ SAGEM S2000PM1		●	●		●	
XSARA PICASSO CHINE	Injection	Petrol engine	6FZ SAGEM S2000PM1		●	●		●	
XSARA PICASSO CHINE	Injection	Petrol engine	6FZ SAGEM S2000PM2		●	●			
XSARA PICASSO CHINE	Injection	Petrol engine	1.6L NFV BOSCH M744	●	●	●	●	●	
XSARA PICASSO CHINE	Injection	Petrol engine	NFS BOSCH ME745	●	●	●	●	●	
XSARA PICASSO CHINE	Injection	Petrol engine	NFU BOSCH ME745	●	●	●	●	●	
XSARA PICASSO CHINE	Injection	Petrol engine	N6A BOSCH ME745	●	●	●	●	●	
XSARA PICASSO CHINE	Injection	Petrol engine	NFR BOSCH ME745	●	●	●	●	●	
XSARA PICASSO CHINE	Injection	Petrol engine	NFS BOSCH ME749	●	●	●	●	●	
XSARA PICASSO CHINE	Injection	Petrol engine	NFU BOSCH ME749	●	●	●	●	●	
XSARA PICASSO CHINE	Anti-lock brake system	ABS8.1 BOSCH		●	●	●	●	●	
XSARA PICASSO CHINE	Anti-lock brake system	ABS8 BOSCH			●	●		●	
XSARA PICASSO CHINE	Anti-lock brake system	ABR5.3		●			●	●	
XSARA PICASSO CHINE	Injection	Petrol engine	N6A BOSCH ME749	●	●	●	●	●	
XSARA PICASSO CHINE	Injection	Diesel engine	2.0 L BOSCH EDC15C2	●	●	●	●	●	
XSARA PICASSO CHINE	Injection	Diesel engine	9HY BOSCH EDC16C3	●	●	●	●	●	
XSARA PICASSO CHINE	Injection	Diesel engine	9HZ (FAP) BOSCH EDC16C34 DV6TED4	●	●	●	●	●	
XSARA PICASSO CHINE	Anti-lock brake system	ESP8.1 BOSCH		●	●	●	●	●	05007
XSARA PICASSO CHINE	Anti-lock brake system	ESP BOSCH5.7		●	●	●	●	●	05003
XSARA PICASSO CHINE	Anti-lock brake system	ESP8 BOSCH			●	●		●	05003
ZX	Engine	Petrol engine	1.1 L HDY/HDZ BOSCH	●			●		
ZX	Engine	Petrol engine	1.4 L KFX MM1AP	●			●		
ZX	Engine	Petrol engine	1.4 L KFX MM1AP	●			●		
ZX	Engine	Petrol engine	1.6 L BFZ SAGEM CCM4GJ	●			●		
ZX	Engine	Petrol engine	2.0 L RFS MM1AP	●			●		
ZX	Engine	Petrol engine	2.0 L RFS MM1AP	●			●		
ZX	Driving assistance	ABS BOSCH 5		●			●		
ZX	Auto gearbox	BVA AL4		●	●	●	●	●	07001
C3 Ai51	Injection/ignition		ME749	●	●	●	●	●	07004
C3 Ai51	Injection/ignition		ME749 EC5	●	●	●	●	●	07004
C3 Ai51	Injection/ignition		V34.4	●	●	●	●	●	07004
C3 Ai51	Injection/ignition		V34.5	●	●	●	●	●	
C3 Ai51	ABS/traction control		ABSMK70 1	●	●	●	●	●	
C3 Ai51	ABS/traction control		ESPMK60 0	●	●	●	●	●	05002
C3 Ai51	Gearbox		BVA AL4	●	●	●	●	●	07004
C3 Ai51	Built-in Systems Interface (BSI)			●	●	●	●	○	
C3 Ai51	Trailer relay unit			●	●	●	●	○	
C3 Ai51	Telematics			●	●	●	●	●	

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
C3 Ai51	Services module			●	●	●	●	●	
C3 Ai51	Instrument panel			●	●	●	●	●	
C3 Ai51	Radio			●	●	●	●	●	
C3 Ai51	Anti-theft alarm			●	●	●	●	●	
C3 Ai51	Driver and passenger airbags		SAC_AUTOLIV	●	●	●	●	○	
C3 Ai51	Air conditioning			●	●	●	●	●	
C3 Ai51	Parking aid			●	●	●	●	○	
C3 Ai51	Rain and brightness sensor (CDPL)			●	●	●	●	○	
C3 Ai51	Switch module under the steering wheel (top of column)			●	●	●	●	●	
C3 Ai52	Electric power steering			●	●	●	●	●	
C-Elysee (M43)	BSI		BSI2010	●	●	●			
C-Elysee (M43)	ABS or ESP ECU		ABSMK100	●	●	●	●	●	07005 08300 08301
C-Elysee (M43)	ABS or ESP ECU		ESPMK100	●	●	●	●	●	07005 08302 08303 08300 08301
C-Elysee (M43)	Multifunction screen		EMF_A_UDS	●	●	●		●	08254
C-Elysee (M43)	Multifunction screen		EMF_C_UDS	●	●	●		●	08254 08083 08263
C-Elysee (M43)	Switch module at the steering wheel		HDC	●	●	●	●	●	
C-Elysee (M43)	Gearbox ECU		BVA_AL4	●	●	●	●	●	07004 08084 08085 07005 08086
C-Elysee (M43)	Gearbox ECU		MAPS_UDS	●	●	●	●	●	08325 08326 08327 08328 08329 08330 08331 08332 08333 08335 08336 08337 08338 08339
C-Elysee (M43)	Engine ECU		V46 21	●	●	●	●	●	08348 08027 08349 07057 08050 08051 08058 08350 08068
C-Elysee (M43)	Engine ECU		EDC17C10_BR2	●	●	●	●	●	08315 07050 07087 07090 07057 07096 08316 07093 07094 07095 08317 07083 07084 07085 07086 07082 07091 07056 08318 08319 08320 08321 08322 07007 07014 07015 07016 07017 07089 08323 08324 04009 07005
C-Elysee (M43)	Engine ECU		ME745_EC5	●	●	●	●	●	08027 07004 08050 08051 08052 08340
C-Elysee (M43)	Engine ECU		V46	●	●	●	●	●	07004 08343 08344 08345 07057 08346
C-Elysee (M43)	Airbag		RBG_UDS	●	●	●	●		08079 08080
C-Elysee (M43)	Electric Power steering		DAE	●	●	●	●		
C-Elysee (M43)	Radio		AUTORADIO	●	●	●	●	●	08267 08251 08304 08266 08265 08305 08306
C-Elysee (M43)	Radio		RD45	●	●	●	●	●	08267 08266 08265
C-Elysee (M43)	Hands free starting access electronic module		BML	●	●	●	●	●	08307 08308 08309 08310 08311 08312 08313 08314

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
C-Elysee (M43)	Parking assistance		AAS UDS	●	●	●	●	●	
C-Elysee (M43)	Siren		SIR	●	●	●	●	●	08342
C-Elysee (M43)	Instrument panel		COMBINE UDS	●	●	●	●	●	
C-Elysee (M43)	Trailer relay unit		BSG 2010_RQ	●	●	●	●	●	
C-Elysee (M43)	Multiplexed additive pump		PADDGO	●	●	●	●	●	07005 08341
C4 L (B7)	Instrument panel		COMBINE UDS	●	●	●	●	●	
C4 L (B7)	Display		EMF_A UDS	●	●	●	●	●	
C4 L (B7)	Display		EMF_C UDS	●	●	●	●	○	
C4 L (B7)	Steering wheel with integral controls (VCI)		VCI	●	●	●	●	●	
C4 L (B7)	Parking aid		AAS UDS	●	●	●	●	○	
C4 L (B7)	Telematics		RADIONAV RNEGC	●	●	●	●	●	
C4 L (B7)	Telematics		RNEG2010	●	●	●	●	●	
C4 L (B7)	Matrix screen integral to the instrument panel		MATT_M_2010	●	●	●	○	●	
C4 L (B7)	Matrix screen integral to the instrument panel		MATT_C_2010	●	●	●	○	●	
C4 L (B7)	Switch module under the steering wheel		HDC	●	●	●	●	●	
C4 L (B7)	Switch module under the steering wheel		COM2008P	●	●	●	●	●	
C4 L (B7)	gearbox		BVA AL4	●	●	●	●	●	07004
C4 L (B7)	gearbox		BVA AM6 AT6 EURO5	●	●	●	●	●	
C4 L (B7)	gearbox		CFC300P	●	●	●	●	●	
C4 L (B7)	Power steering electric pump unit		GEP	●	●	●	●	●	
C4 L (B7)	Anti-theft alarm		ALARME	●	●	●	●	●	
C4 L (B7)	Under inflation detection		DSG	●	●	●	●	●	02001 02002 02003 02004 02009 02011 02012
C4 L (B7)	Air conditioning ECU		CLIM REGULEE UDS	●	●	●	●	●	
C4 L (B7)	Rain sensor		PLUIE LUMINOSITE UDS	●	●	●	●	○	
C4 L (B7)	Radio		RD5	●	●	●	●	●	
C4 L (B7)	Built-in Systems Interface		BSI2010	●	●	●	●	●	
C4 L (B7)	Air-bag		RBG UDS	●	●	●	●	○	
C4 L (B7)	Multiplexed control panel		Accessory audio system and manual air conditioning	●	●	●	●	●	
C4 L (B7)	Engine ECU		MED17.4.2	●	●	●	●	●	07004
C4 L (B7)	Engine ECU		ME745 EC5	●	●	●	●	●	
C4 L (B7)	Engine relay unit		BSM 2010	●	●	●	●	●	
C4 L (B7)	ABS/traction control		81 ESP	●	●	●	●	●	01003 01008 05001
C4 L (B7)	Battery charge status unit		BECB GEN2	●	●	●	●	○	
C4 L (B7)	Supply protection and management unit		BPGA2010	●	●	●	●	○	
C4 L (B7)	Hands-free control unit		BML	●	●	●	●	○	
C4 L (B7)	Electric steering lock		AVE	●	●	●	●	●	
C4 L (B7)	Electronic key reader		LCE	●	●	●	●	○	

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
Berlingo Electric	BSI		BSI	●	●	●	●	●	
Berlingo Electric	Engine relay unit		BSM	●	●	●	●	●	
Berlingo Electric (B9E)	Traction battery cell electronics		CMU_01	●	○	○	●	○	
Berlingo Electric (B9E)	Traction battery cell electronics		CMU_02	●	○	○	●	○	
Berlingo Electric (B9E)	Traction battery cell electronics		CMU_03	●	○	○	●	○	
Berlingo Electric (B9E)	Traction battery cell electronics		CMU_04	●	○	○	●	○	
Berlingo Electric (B9E)	Traction battery cell electronics		CMU_05	●	○	○	●	○	
Berlingo Electric (B9E)	Traction battery cell electronics		CMU_06	●	○	○	●	○	
Berlingo Electric (B9E)	Traction battery cell electronics		CMU_07	●	○	○	●	○	
Berlingo Electric (B9E)	Traction battery cell electronics		CMU_08	●	○	○	●	○	
Berlingo Electric (B9E)	Traction battery cell electronics		CMU_09	●	○	○	●	○	
Berlingo Electric (B9E)	Traction battery cell electronics		CMU_10	●	○	○	●	○	
Berlingo Electric (B9E)	Electric machine management ECU		MCU	●	●	●	●	○	
Berlingo Electric (B9E)	Electric vehicle management ECU		EV_ECU	●	●	●	●	○	
Berlingo Electric	ABS or ESP ECU		ESP81	●	●	●	●	●	
Berlingo Electric	air conditioning compressor		CCE	●	●	●	●	●	
Berlingo Electric	Air conditioning ECU		CLIM_REGULEE	●	●	●	●	●	
Berlingo Electric	Air conditioning ECU		CLIM	●	●	●	●	●	
Berlingo Electric	Airbag		SAC_AUTOLIV	●	●	●	●	○	
Berlingo Electric	Alarm		ALARME	●	●	●	●	●	
Berlingo Electric (B9E)	Battery charge status unit Generation 2		BECB_GEN2_VE	●	●	●	●	○	
Berlingo Electric	Drive train interface ECU		PIU	●	●	●	●	●	
Berlingo Electric	Instrument panel		COMBINE	●	●	●	●	●	
Berlingo Electric	Multifunction display		EMF_A	●	●	●	●	●	
Berlingo Electric	Multifunction display		EMF_C	●	●	●	●	●	
Berlingo Electric (B9E)	Onboard charger of the traction battery		OBC_DCDC	●	●	●	●	○	
Berlingo Electric	Parking aid		AAS	●	●	●	●	○	
Berlingo Electric (B9E)	Passenger compartment air heating resistor		CTPA	●	●	●	●	○	
Berlingo Electric (B9E)	Power steering electric pump unit		GEP	●	●	●	●	●	
Berlingo Electric	Radio		AUTORADIO	●	●	●	●	●	
Berlingo Electric	Radio		RD45	●	●	●	●	●	

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
Berlingo Electric	Rain sensor		PLUIE LUMINOSITE	●	●	●	○	○	
Berlingo Electric	Service module		BTA	●	●	●	●	●	
Berlingo Electric (B9E)	Switch module under the steering wheel (Top of column)		HDC	●	●	●	●	●	
Berlingo Electric	Telematics		RADIONAV_RNEG	●	●	●	●	●	
Berlingo Electric	Telematics		RNEG2010	●	●	●	●	●	
Berlingo Electric	Traction battery ECU		BMU	●	●	●	●	○	
C4 PICASSO (B78)	BSI		BSI2010	●	●	●	●	●	
C4 PICASSO (B78)	Injection		EDC17C10_BR2	●	●	●	●	●	
C4 PICASSO (B78)	Injection		HDI_SID807_BR2	●	●	●	●	●	
C4 PICASSO (B78)	Injection		MED17_4_2	●	●	●	●	●	
C4 PICASSO (B78)	Injection		MEV17_4_2	●	●	●	●	●	
C4 PICASSO (B78)	Injection		DCM62	●	●	●	●	●	
C4 PICASSO (B78)	Injection		MED17_4_4	●	●	●	●	●	
C4 PICASSO (B78)	Electric power steering		DAE_BVH2	●	●	●	●	○	
C4 PICASSO (B78)	Electric steering lock		AVE	●	●	●	●	●	
C4 PICASSO (B78)	Electronic key reader		LCE	●	●	●	●	○	
C4 PICASSO (B78)	Engine relay unit		BSM_2010	●	●	●	●	●	
C4 PICASSO (B78)	ABS		ESP90	●	●	●	●	●	
C4 PICASSO (B78)	Additional heating		CHAUFF_ADD	●	●	●	●	●	
C4 PICASSO (B78)	Air conditioning		BCC	●	●	●	●	●	
C4 PICASSO (B78)	Airbag		RBG_UDS	●	●	●	●	○	
C4 PICASSO (B78)	Anti-theft alarm		MUS	●	●	●	●	●	
C4 PICASSO (B78)	audio amplifier		AMPLI_AUDIO	●	●	●	○	●	
C4 PICASSO (B78)	Automatic gearbox electric control		COMELEC2	●	●	●	●	●	
C4 PICASSO (B78)	Battery charge status unit		BECB_GEN2	●	●	●	●	○	
C4 PICASSO (B78)	CD player		CDE	●	●	●	●	●	
C4 PICASSO (B78)	Control panel		CIROCCO	●	●	●	●	●	
C4 PICASSO (B78)	Control panel		COMBINE_UDS	●	●	●	●	●	
C4 PICASSO (B78)	Diesel additive function		PADDGO_INERGY	●	●	●	●	●	
C4 PICASSO (B78)	Discharge bulbs vertical and horizontal adjustment		LADCT	●	●	●	●	●	
C4 PICASSO (B78)	Door control pad		PDPC_UDS	●	●	●	●	●	
C4 PICASSO (B78)	Switch module under the steering wheel (Top of column)		COM2008P	●	●	●	●	●	
C4 PICASSO (B78)	Trailer relay unit		BSG_2010_RQ	●	●	●	●	●	
C4 PICASSO (B78)	Vehicle Distance Assistance		ARTIV_UDS	●	●	●	●	●	
C4 PICASSO (B78)	Panoramic visual assistance front camera		AVP	●	●	●	●	●	
C4 PICASSO (B78)	Driver's seat memorizing unit		BDMC	●	●	●	●	●	
C4 PICASSO (B78)	Gearbox		BVA_AM6_AT6_UDS	●	●	●	●	●	
C4 PICASSO (B78)	Gearbox		CFC300P	●	●	●	●	●	

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
C4 PICASSO (B78)	Hands free starting access electronic module		BML	●	●	●	●	●	
C4 PICASSO (B78)	Independent telematic unit (BTA)		BTA	●	●	●	●	●	
C4 PICASSO (B78)	Left hand front wiper motor		MOTEV UDS	●	●	●	●	●	
C4 PICASSO (B78)	LH reversible seat belt reel		ECR_G	●	●	●	●	●	
C4 PICASSO (B78)	Motorised Boot ECU		VERINS_MOTORISES	●	●	●	●	●	
C4 PICASSO (B78)	Multifunction camera or multifunction video camera		CVM	●	●	●	●	●	
C4 PICASSO (B78)	Multiplexed control panel		FMUX	●	●	●	●	●	
C4 PICASSO (B78)	Parking aid		AAS UDS	●	●	●	●	○	
C4 PICASSO (B78)	Rain and brightness sensor		PLUIE_LUMINOSITE_UDS	●	●	●	●	○	
C4 PICASSO (B78)	RH reversible seat belt reel		ECR_D	●	●	●	●	●	
C4 PICASSO (B78)	Right hand front wiper motor		MOTED UDS	●	●	●	●	●	
C4 PICASSO (B78)	Signalling fuse box		BSG S	●	●	●	●	●	
C4 PICASSO (B78)	Siren		SIR	●	●	●	●	●	
C4 PICASSO (B78)	Steering wheel with integral controls (VCI)		VCI	●	●	●	●	●	
C4 PICASSO (B78)	Supply protection and management unit		BPGA2010	●	●	●	●	○	
C4 PICASSO (B78)	Telematics unit		SMEG_PLUS	●	●	●	●	●	
DS 5LS	BSI		BSI2010	●	●	●	●	●	
DS 5LS	Engine ECU		MED17_4_2	●	●	●	●	●	
DS 5LS	Engine ECU		MEVD17_4_2	●	●	●	●	●	
DS 5LS	Engine ECU		V46_32	●	●	●	●	●	
DS 5LS	Electric secondary brake		FSE	●	●	●	●	●	
DS 5LS	Electric steering lock		AVE	●	●	●	●	●	
DS 5LS	Electronic key reader		LCE	●	●	●	●	●	
DS 5LS	Engine relay unit		BSM_2010	●	●	●	●	●	
DS 5LS	ABS		ESP81	●	●	●	●	●	
DS 5LS	Air conditioning ECU		CLIM_REGULEE_UDS	●	●	●	●	●	
DS 5LS	Airbag		RBG UDS	●	●	●	●	○	
DS 5LS	Anti-theft alarm		ALARME	●	●	●	●	●	
DS 5LS	audio amplifier		AMPLI_AUDIO	●	●	●	○	●	
DS 5LS	Battery charge status unit		BECEB_GEN2	●	●	●	●	○	
DS 5LS	Central voltage retention device		DMTR	●	●	●	○	○	
DS 5LS	Discharge bulbs vertical and horizontal adjustment		LADCT	●	●	●	●	●	
DS 5LS	Display		EMF_A UDS	●	●	●	○	●	
DS 5LS	Display		EMF_C UDS	●	●	●	○	●	
DS 5LS	Hands free starting access electronic module		BML	●	●	●	●	●	

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
DS 5LS	Independent telematic unit (BTA)		BTA CN	●	●	●	●	●	
DS 5LS	Matrix screen integral to the instrument panel		MATT C 2010	●	●	●	○	●	
DS 5LS	Matrix screen integral to the instrument panel		MATT M 2010	●	●	●	○	●	
DS 5LS	Steering wheel with integral controls (VCI)		VCI	●	●	●	●	●	
DS 5LS	Supply protection and management unit		BPGA2010	●	●	●	●	○	
DS 5LS	Switch module under the steering wheel (Top of column)		COM2008P	●	●	●	●	●	
DS 5LS	Under inflation detection		DSG UDS	●	●	●	●	○	
DS 5LS	Gearbox		BVA AM6 AT6 EURO5	●	●	●	●	●	
DS 5LS	Instrument panel		COMBINE UDS	●	●	●	●	●	
DS 5LS	Multiplexed control panel		FMUX	●	●	●	●	●	
DS 5LS	Parking aid		AAS UDS	●	●	●	●	○	
DS 5LS	Power steering electric pump unit		GEP	●	●	●	●	●	
DS 5LS	Radio		RD45	●	●	●	●	●	
DS 5LS	Rain and brightness sensor		PLUIE LUMINOSITE UDS	●	●	●	●	○	
DS 5LS	Telematic		MRN	●	●	●	●	●	

Special_Function

Index	Specil Function Name	Index	Specil Function Name
01001	Cable tensioning	01002	Clutch pedal position sensor calibration
01003	Deactivation of the automatic application of the electric parking brake function	01004	Longitudinal acceleration sensor calibration
01005	Electric parking brake calibration	01006	Put in fitting / removal position
01007	Part removal / refitting	01008	Reactivation of automatic application of the electric parking brake
01009	Slope sensor calibration	02001	Deactivation / Activation of the tyre under-inflation detection function
02002	Erasing of the secondary wheels	02003	Wheel transmitter module management
02004	Initialisation of a single wheel transmitter module	02005	Valve search faulty
02006	Initialisation of the wheel transmitter modules	02007	Program additional wheel set
02008	Program wheel transmitter modules of main wheel set	02009	Read wheel transmitter module identifiers
02010	Tyre pressure detector activation / deactivation	02011	Valve programming check
02012	Write wheel transmitter module identifiers by references	03001	EU10
03002	EU11	03003	Maintenance limit
03004	Option INT	03005	Reset maintenance indicator
03006	Reset maintenance information	03007	Reset maintenance mileage
03008	Reset maintenance mileage + maintenance number	03009	Reset maintenance number done
04001	Configuration of the amount of additive in the particle filter	04002	Filling of the diesel additive adding reservoir
04003	Filling of the diesel additive tank	04004	Forced particle filter regeneration
04005	Forced regeneration of the particle filter, vehicle stationary	04006	Forced regeneration, vehicle stationary
04007	Particle filter regeneration	04008	Particle filter replacement
04009	Programming of the total quantity of additive injected into the particulate emission filter	04010	Repair to the diesel additive system
04011	Replacement of the diesel additive reservoir, of the pump or of the pipes	04012	Replacement of the particle emission filter
04013	Replacement or filling of the diesel additive tank	05001	Calibration of the steering wheel angle sensor
05002	Calibration of the steering wheel angle sensor : C2, C3, C3 pluriel, New Look C5 with ESP MK60	05003	Calibration/decablation of the steering wheel angle sensor
05004	Definition of the steering wheel with fixed central controls configurable control menu	05005	Reading of the calibration status of the steering wheel angle
05006	Steering wheel angle calibration	05007	Steering wheel angle sensor calibration
05008	Steering wheel angle sensor programming	06001	Bleeding
07001	Initialisation of auto-adaptation	07002	Initialisation of the autoadaptive values
07003	Initialise auto-adaptives	07004	Initialising the autoadaptives
07005	Manual configuration	07006	Air Flow Sensor Replacement
07007	Classification of the 4 injectors	07008	Differential pressure sensor
07009	Egr electrovalve	07010	Electric EGR valve replacement
07011	Filling of the additive reservoir	07012	Flowmeter
07013	High pressure pump	07014	Injector 1 classification
07015	Injector 2 classification	07016	Injector 3 classification
07017	Injector 4 classification	07018	Pairing
07019	Replacement Of 4 Injectors	07020	Replacement of injector 1
07021	Replacement of injector 2	07022	Replacement of injector 3
07023	Replacement of injector 4	07050	Replacement of the additive reservoir, of the pump or of the pipes
07051	Replacement of the differential pressure sensor	07052	Replacement Of The High Pressure Pump Or The Flow Regulation Valve
07053	Replacement Of The Turbo	07054	Turbo

Index	Specil Function Name	Index	Specil Function Name
07055	Forced regeneration, vehicle moving	07056	Change of engine block without the flowmeter
07057	Checking the immobiliser code in the engine management ecu	07058	Replacement of the cooling fan
07059	Replacement of the diesel high pressure rail	07060	Replacement of the engine block and cylinder head with the flowmeter
07080	Replacement of the fuel flow regulator	07081	Replacement of the particle emission filter differential pressure sensor
07082	Initialisation of the 4 diesel injectors	07083	Initialisation of diesel injector 1
07084	Initialisation of diesel injector 2	07085	Initialisation of diesel injector 3
07086	Initialisation of diesel injector 4	07087	Change of air mixer
07088	Change of ras (turbo air cooler) by-pass	07089	Replacement of the oxygen sensor
07090	Change of EGR valve	07091	Change of engine block with the flowmeter
07092	Replacement of the ancillaries drive belt	07093	Replacement of the cylinder head
07094	Replacement of the EGR exchanger	07095	Replacement of the exhaust manifold
07096	Replacement Of The Particle Filter	08000	EGR mixer butterfly replacement
08001	Replacement of the egr doser butterfly and replacement of the egr doser by-pass butterfly	08002	Priming of the additive system if replacing parts (additive reservoir, pump or pipes)
08003	Initialisation of the additive level when filling or replacing the additive reservoir	08004	Injector characterisation IMA 4 pts
08005	Injector characterisation IMA 5 pts	08006	Initialisation of the air flow sensor
08007	Initialisation of the EGR butterfly	08008	Initialisation of the EGR valve
08009	Initialisation of the engine ECU	08010	Initialisation of the turbocharger 2 turbine valve (VT2)
08011	O2 sensor initialisation	08012	Replacement of the turbocharger turbine valve 2
08013	Replacement of the exhaust gas recycling valve	08014	Replacement Of The Impeller Block
08015	Replacement Of The Cylinder Block Bearing	08016	Replacement of the EGR exchanger by-pass
08017	Replacement Of The Flowmeter	08018	Replacement Of The Engine Block Without The Flowmeter
08019	Replacement Of The Exchanger Of The Exhaust Gas Recycling Solenoid	08020	Egr Valve Programming
08021	Initialisation Of The Air Mixer	08022	Initialisation Of The Oxygen Sensor
08023	Change of high pressure pump with its fuel flow regulator	08024	Replacement of the power accumulator or of the voltage retaining device
08025	Replacement of the reversible alternator	08026	Temporary reactivation of the stop and start function (for a maximum distance of 10 km)
08027	Accelerator pedal sensor	08028	Control unit
08029	Fuel pump	08050	Injectors
08051	Motorised throttle unit	08052	Oxygen sensors
08053	Canister discharge electrovalve	08054	Catalytic converter
08055	Check the timing adjustment	08056	Fuel pressure regulation electrovalve
08057	Fuel HP pump	08058	Inlet camshaft dephaser
08059	Inlet camshaft dephasing electrovalve	08060	Inlet pressure sensor
08061	Rail pressure sensor	08062	Upstream and downstream oxygen sensors
08063	Camshaft phase sensor	08064	Timing
08065	Inlet and exhaust camshaft dephaser	08066	Variable valve lift motor
08067	Variable valve lift system position sensor	08068	Cylinder reference sensor
08069	Write VIN	08070	Configuration of the quantity of additive present in the particle emission filter
08071	Top up diesel additive tank	08072	Initialising of the active damper
08073	Interrogation of the status of the active damper function	08074	Reactivation of the function
08075	Satellites	08076	Front airbags
08077	Pre-tensioners	08078	Side air bags
08079	Locking	08080	Unlocking
08081	Configuration of the detection peak	08082	Thatcham mode configuration
08083	Vehicle configuration	08084	Identification of the configuration
08085	Accelerator pedal initialisation	08086	Oil wear counter
08087	Reading of the oil wear counter	08088	Programming of the neutral position
08089	Replacement of the automatic gearbox and its ECU	08090	Replacement of the automatic gearbox oil

Index	Specil Function Name	Index	Specil Function Name
08091	Replacement of the automatic gearbox without its ECU	08092	Semi-automatic configuration
08093	Writing to oil wear counter	08094	Replacement of the ECU without the automatic gearbox
08095	Depressurisation of the hydraulic circuit	08096	Pressurise the hydraulic circuit
08097	Bleeding of the hydraulic circuit	08098	Gearbox programming
08099	Removal/refitting or replacement of the gearbox ecu	08200	Replacement of the hydraulic clutch bearing
08201	Check of the gearbox control actuator oil level	08202	Draining of the gearbox control actuator oil
08203	Removal/refitting or replacement of a gearbox control actuator position sensor	08204	Removal/refitting or replacement of the electropump assembly
08205	Removal/refitting or replacement of the gearbox control actuator	08206	Removal/refitting or replacement of a solenoid valve or of the pressure sensor
08207	Removal/refitting or replacement of the control actuator reservoir or of the accumulator	08208	Removal/refitting or replacement of the electropump assembly electric motor
08209	Removal/refitting or replacement of the clutch cover or of the clutch disc	08210	Removal/refitting or replacement of the gearbox
08211	Replacement of the gear lever	08212	Replacement of the paddles at the steering wheel
08213	Read / write counters	08214	Vehicle height sensor programming
08250	Audio parameter configuration	08251	Configuration of the Hands Free Kit
08252	Configuration of the audio parameters	08253	Configuration of the instrument panel
08254	Customer configuration	08255	Orientation of infrared sensors
08256	Erasing sensor addresses	08257	Sensor programming
08258	Sensor programming check	08259	Erasing of the customisable position programmed by the motorised tailgate
08260	Erasing of the motorised tailgate programming	08261	Programming of the motorised tailgate customisable position
08262	Reinitialisation of the motor's thermal protection	08263	Personalisation menu configuration
08264	Overall check of the sensors	08265	Antenna configuration
08266	Radio configuration	08267	VIN code
08268	Different configuration for the 16 levels	08269	Identical configuration for the 16 levels
08270	Configuration of vehicle options	08271	VIN configuration
08272	Configuration of client services	08273	Vehicle reference height adjustment
08274	Depressurise	08275	Programming of the heights
08300	Tyre above specification	08301	Bleeding of the hydraulic block ABS MK100
08302	Calibration of the gyrometer/accelerometre sensor	08303	Replacement of the ECU ABS
08304	Configuration of the screen	08305	Illumination table/button lighting level
08306	Illumination table/screen lighting level	08307	Check of the detection of a hands-free remote control by the front left door handle aerial
08308	Check of the detection of a hands-free remote control by the front right door handle aerial	08309	Check of the detection of a hands-free remote control by the boot external aerial
08310	Check of the detection of a hands-free remote control inside the vehicle (dashboard)	08311	Check of the detection of a hands-free remote control inside the vehicle (central armrest)
08312	Check of the detection of a hands-free remote control inside the vehicle's boot	08313	Check of the detection of a hands-free remote control located outside the vehicle
08314	Check of the detection of a hands-free remote control inside the vehicle (inside front and boot)	08315	Filling of the additive reservoir or pouch
08316	High Pressure Pump Replacement	08317	Replacement of the turbo
08318	Change To The Air Flowmeter	08319	Injector 1 replacement
08320	Injector 2 replacement	08321	Injector 3 replacement
08322	Injector 4 replacement	08323	Replacement Of 4 Injectors
08324	Programing Of The Quantity Of Additive Remaining In The Reservoir	08325	Setting of the gearbox actuator to the removal position

Index	Specil Function Name	Index	Specil Function Name
08326	Setting of the gearbox actuator to the fitting position	08327	Sequence of programming operations
08328	Clutch actuators programming operations	08329	Gearbox actuator programming operations
08330	Initilisation of the gearbox actuator	08331	Replacement of the piloted manual gearbox and of the piloted manual gearbox actuators
08332	Replacement of the gearbox	08333	Replacement of the gearbox actuator
08334	Replacement of the gear lever	08335	Replacement of the clutch
08336	Replacement of the clutch actuator	08337	Counters
08338	Repalcing the gearbox ECU	08339	Replacement of the piloted manual gearbox and of the piloted manual gearbox ECU
08340	Replacement of the vacuum pump	08341	Replacement of the additive tank
08342	Configuration of the intrusion alarm siren	08343	Replacement of the motorrised butterfly housing
08344	Replacement of the acclerator pedal	08345	Replacement of injectors
08346	Engine speed sensor programming procedure	08347	Learninig pairing
08348	All the engine management ECU programmed auto-adaptive values	08349	Vacuum pump
08350	Inlet camshaft dephaser solenoid valve		